

Module Communications Network - Communications Network - Overview

Description and Operation

OVERVIEW

A number of different types of communication network are incorporated into the vehicle wiring harnesses for the transmission of commands and information between control modules. The configuration installed on a particular vehicle depends on the model and equipment level.



NOTE: The control diagrams shown later in this section are schematics reflecting communications networks fitted to LH (left-hand) vehicles only. For detailed layouts of the various communications networks fitted to LHD (left-hand drive) and RHD (right-hand drive) vehicles, refer to the Electrical Guide.

The communications networks available on the vehicle are shown in the table below.

| Network | Baud Rate |
|--|-------------|
| LIN (local interconnect network) bus | 9.6 kbits/s |
| Medium speed CAN (controller area network) bus | 125 kbits/s |
| High speed CAN bus | 500 kbits/s |
| Media Orientated System Transport (MOST) ring | 24 mbits/s |


Module Communications Network - Communications Network - System Operation and Component Description

Description and Operation

Control Diagram




CONTROL DIAGRAM - LIN BUS - SHEET 1 OF 2



E94378

| Item | Description |
|------|---|
| | O = LIN (local interconnect network) bus |
| 1 | CJB (central junction box) |
| 2 | Battery backed sounder |
| 3 | Intrusion detection module |


| | |
|----|---|
| 4 | Rain/Light sensor |
| 5 | RJB (rear junction box) |
| 6 | Battery monitoring system module |
| 7 | Rear view camera |
| 8 | TCM (transmission control module) |
| 9 | Generator |
| 10 | Driver's door switch pack |
| 11 | Rear door control module |
| 12 | Driver's door control module |
| 13 | ECM (engine control module) |
| 14 | Electronic transmission selector |
| 15 | Driver's seat module |
| 16 | Driver's seat switch pack |
| 17 | Rear door control module |
| 18 | Front passenger door control module |
| 19 | Clockspring |
| 20 | Audio and telephone steering wheel switches |
| 21 | Instrument cluster |
| 22 | Start control module |



E94457

| Item | Description |
|------|---|
| | O = LIN bus |
| 1 | ATC (automatic temperature control) module |
| 2 | Stepper motor - Windshield defrost |
| 3 | Stepper motor - Face/feet distribution |
| 4 | Stepper motor - LH (left-hand) temperature blend |
| 5 | Stepper motor - RH (right-hand) temperature blend |
| 6 | Electric booster heater |
| 7 | Stepper motor - RH outer face level vent |
| 8 | Stepper motor - RH inner face level vent |
| 9 | Stepper motor - LH inner face level vent |
| 10 | Stepper motor - LH outer face level vent |

CONTROL DIAGRAM - MEDIUM SPEED CAN BUS




E94379

| Item | Description |
|------|---|
| | N = Medium speed CAN (controller area network) bus |
| 1 | Parking aid module |
| 2 | RJB |
| 3 | Keyless vehicle module |
| 4 | RH blind spot monitoring module |
| 5 | Driver's seat module |
| 6 | Front seat climate control module |
| 7 | Information control module |
| 8 | ATC module |
| 9 | CJB |
| 10 | Diagnostic socket |
| 11 | Instrument cluster |
| 12 | Integrated control panel |
| 13 | Front passenger door control module |

| | |
|----|---|
| 14 | Tire Pressure Monitoring System (TPMS) module |
| 15 | Driver's door control module |
| 16 | LH blind spot monitoring module |

CONTROL DIAGRAM - HIGH SPEED CAN BUS




E94380

| Item | Description |
|------|---|
| | D = High speed CAN bus |
| 1 | Electric steering column lock |
| 2 | Instrument cluster |
| 3 | Diagnostic socket |
| 4 | Adaptive speed control module |
| 5 | Electronic transmission selector |
| 6 | Occupant classification system control module |
| 7 | Headlamp leveling module |
| 8 | ABS (anti-lock brake system) module |

| | |
|----|---|
| 9 | ECM |
| 10 | TCM |
| 11 | Pedestrian protection system control module |
| 12 | Electric park brake module |
| 13 | RCM (restraints control module) |
| 14 | Adaptive damping control module |

CONTROL DIAGRAM - MOST RING



E94381

| Item | Description |
|------|-------------------------------------|
| | P = MOST ring |
| 1 | Entertainment system control module |
| 2 | Software download socket |
| 3 | Touch Screen Display (TSD) |
| 4 | Portable audio interface |
| 5 | Bluetooth® telephone module |

| | |
|----|-------------------------|
| 6 | Integrated audio module |
| 7 | Multi-media module |
| 8 | DAB/SDARS receiver |
| 9 | Television (TV) tuner |
| 10 | Audio system amplifier |

System Operation

OPERATION

Refer to the relevant system section for details of system operation.

Component Description

DESCRIPTION

Refer to the relevant system section for details of system description.

Module Communications Network - Communications Network

Diagnosis and Testing

Principles of Operation

For a detailed description of the Communications Network, refer to the relevant Description and Operation sections in the workshop manual. REFER to: (418-00 Module Communications Network)

Communications Network (Description and Operation),
[Communications Network](#) (Description and Operation),
[Communications Network](#) (Description and Operation).

Inspection and Verification

CAUTIONS:



Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.



Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage may result.

1. Verify the customer concern
2. Visually inspect for obvious signs of damage and system integrity

Visual Inspection

| Electrical |
|---|
| <ul style="list-style-type: none"> • Fuses (refer to electrical guide) • Wiring harness • Correct engagement of electrical connectors • Loose or corroded connections • Routing of fibre optic harnesses • Correct engagement of optical connectors • Correct placement of optical connectors (ring order) • Correct assembly of optical connectors (backout, etc) • Damage to fibre (chafing, abrasion, kinking, cuts, etc) |

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
4. If the cause is not visually evident, check for Diagnostic Trouble Codes (DTCs) and refer to the DTC Index

Symptom Chart

| Symptom | Possible Causes | Action |
|--|--|--|
| MOST network fault - Touch screen display displaying flashing logo | <ul style="list-style-type: none"> • MOST ring broken after the touch screen display • Control module on MOST network power or ground circuit open circuit, high resistance • Control module on MOST network internal failure | <ul style="list-style-type: none"> • GO to Pinpoint Test B. |
| MOST network fault - Touch screen display blank | <ul style="list-style-type: none"> • MOST ring broken between the information and entertainment control module and the touch screen display • Information and entertainment control module or touch screen display power or ground circuit open circuit, high resistance • Wake up signal not received by the information and entertainment control module • Information and entertainment control module or touch screen display internal failure | <ul style="list-style-type: none"> • GO to Pinpoint Test H. |

Controller Area Network (CAN)

Control Module Connections to the CAN Harness

Control modules are connected to the CAN harness either in a 'loop' or 'spur' configuration. In the 'loop' type configuration the CAN harness loops into the module (via two connector pins) and then loops out of the module (via another two connector pins). In the 'spur' type configuration, a harness spur is spliced into the main 'backbone' of the CAN harness and the module is connected to the harness spur via two connector pins.

CAN Harness Architecture

For a detailed description of the CAN Networks and architecture, refer to the relevant Description and Operation section in the Workshop Manual.

CAN Network Integrity Tests

If a control module is suspected of non-communication, the Network Integrity test application available on the manufacturer approved diagnostic system can be used to confirm if communication is possible between the control modules on the vehicle and the manufacturer approved diagnostic system (via the J1962 diagnostic connector). The results from the test can be used to determine if either a single module or multiple modules are failing to communicate.

CAN Terminating Modules

If the Network Integrity test indicates that one or more module on one of the CAN networks (HS or MS) are failing to communicate, there are several checks that can be made. The first step is to identify if both of the CAN terminating modules on each individual CAN Bus are communicating. If both CAN terminating modules for each individual CAN Bus are communicating (identified via the Network Integrity test), then it can be confirmed that the main 'backbone' of the CAN harness is complete. The main 'backbone' of the CAN harness consists of all the modules connected to the CAN harness via a 'loop' configuration and also includes the two terminating modules.

Communication with both CAN terminating modules via the Network Integrity test confirms the physical integrity of the main 'backbone' of the CAN harness (and the harness spur to the J1962 diagnostic connector). This means that there is no requirement to check the resistance of the CAN Network. This is because the standard check for 60 ohms across the CAN High and CAN Low lines will not provide any additional information regarding the physical condition of the CAN harness, beyond what has already been determined from the Network Integrity test.

Non-Communication of a Terminating Module

If a Network Integrity test reveals a terminating module is failing to communicate it can indicate a break in the main 'backbone' of the CAN harness. The first checks should always be to confirm the power and ground supplies to the non-communicating module are correct. Providing these are correct, the resistance between the CAN High and CAN Low lines at the J1962 connector can be checked to determine the integrity of the main 'backbone' of the CAN harness. After disconnecting the battery a reading of 120 ohms would indicate an open circuit in the main 'backbone' of the CAN harness. Alternatively, a reading of 60 ohms would indicate that there is no open circuit fault with the main 'backbone' of the CAN harness.

It is worth noting that even if one of the terminating modules is disconnected from the CAN harness, communications between the modules still connected may still be possible. Therefore communication between the manufacturer approved diagnostic system and the connected modules may also be possible.

Locating CAN Harness Open Circuits

In the case where multiple modules, including a terminating module, are failing to communicate, having first confirmed the power and ground supplies are correct, the approximate location of the open circuit can be identified from analysis of the Network Integrity test results and reference to the relevant CAN network circuit diagrams. For example, if an open circuit existed in a certain position on the CAN harness, any module positioned on the Network between the J1962 connector and the open circuit should return a response during the Network Integrity test. No responses would be returned from any modules past the open circuit fault in the Network.

CAN Harness 'Spur' Type Configuration Circuits

If, after the initial checks (Network Integrity test using the manufacturer approved diagnostic system, and power and ground supplies to the module have been checked and confirmed as correct), a module that is connected to the CAN harness via a 'spur' type configuration is suspected of not communicating, then the physical integrity of the CAN harness 'spur' can be checked.

This is most easily undertaken by individually checking the continuity of the CAN High and CAN Low lines between the non-communicating module connector (with the module disconnected) and the J1962 diagnostic connector.

'Lost Communications' DTCs

As well as the methods described so far in this document, which can be used to determine the location of an open circuit in the CAN harness, 'Lost Communications' DTCs can also be used for this purpose. Lost communication DTCs mean that a module is not receiving CAN information from another module.


For example, if a global DTC read were to be carried out, only DTCs stored in the modules that the manufacturer approved diagnostic system could communicate with would be displayed. If there was an open circuit fault in a certain position on the CAN harness, the modules that could display DTCs would all be prior to the open circuit on the Network, and these modules should display 'Lost Communications' DTCs with all the modules located on the Network past the open circuit fault.

'Bus off' DTCs

The references to bus and its condition refer to the network concerned and the modules on that network.

If a module logs a 'Bus Off' DTC, it means that the module has detected CAN transmission errors and has disabled its own CAN transmissions and disconnected itself from the network in an attempt to allow the rest of the network to function. At this point the 'Bus Off' DTC is set. A common cause of 'Bus Off' DTCs can be a short circuit in the CAN network.

Media Oriented Systems Transport (MOST)



E151896



NOTE: Items 1, 2, 3 and 6 will always be present. The remaining items are optional and/or market specific.

| Item | Description |
|------|--|
| 1 | Information and entertainment control module |
| 2 | MOST diagnostic connector |
| 3 | Touch screen display |
| 4 | Telephone module |
| 5 | Portable audio interface module |
| 6 | Integrated audio module |
| 7 | Power amplifier |
| 8 | Navigation control module |
| 9 | DAB tuner module |
| 10 | Television receiver |

Overview


The basic guidelines are covered in the description and operation section, such as not attempting to repair fibre optic cables, but additional precautions include:

- Do not touch the exposed ends of the optical fibres (grease from skin can contaminate the fibre)

- Whenever the fibre optic cable is disconnected, cover the connectors to prevent dust contamination
- Do not expose the fibre optic cable to heat
- Do not bend the fibre optic cable through less than a 25 mm (one inch) radius
- Do not use laser pens to test the fibre optic cable's ability to pass light


MOST Diagnostic Tools

There are two dedicated tools for testing the MOST system:



E150402

MOST tester. The MOST tester is connected to the MOST network in place of a control module. It will confirm receipt of any existing MOST signal and transmit it to the next control module on the network. Perform the following tests to validate the operation of the MOST tester. GO to Pinpoint Test [A](#).



E150401

MOST prism. The MOST prism is connected in the same way as the MOST tester but will simply reflect any existing signal onward to the next control module. Using the MOST prism before or after a long run of harness may cause a ring break as a good signal may be too weak after travelling the extended distance. Also, the MOST prism will pass light in either direction so will not detect reversed MOST terminals elsewhere in the network. For these reasons, the MOST tester is the preferred tool and should be used unless limited access does not permit it

MOST Ring Break Indication

A ring break in the MOST network is indicated by a blank touch screen display if the break is before the touch screen display or a flashing logo of the break is after the touch screen display. Possible causes of ring breaks are listed in the symptom chart

Pinpoint Tests


| PINPOINT TEST A : MOST TESTER TESTS | |
|-------------------------------------|--|
| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS |
| A1: MOST TESTER BATTERY TEST | |
| 1 | Set the MOST tester power switch to 'on' |

| | |
|--|--|
| | Is the power LED illuminated? Yes Test passed. GO to A2. No Test failed. Install a new battery into the MOST tester. GO to A1. |
|--|--|

A2: 2+0 INPUT/OUTPUT TEST

NOTES:

 2+0' indicates that the loop harness connector consists of 2 fibre optic terminals and 0 electrical terminals.

 The MOST tester may continue to emit a tone or illuminate the LED after the test switch is released. This does not indicate a fault.


- | | |
|----------|---|
| 1 | Set the MOST tester power switch to 'on' |
| 2 | Set the connector selector switch to '2+0' |
| 3 | Set the indication switch to 'beep' or 'LED' |
| 4 | Remove the covers from the MOST tester 2+0 connector and the 2+0 loop harness connector |
| 5 | Connect the 2+0 loop harness to the MOST tester 2+0 connector |
| 6 | Operate the test switch and check the MOST tester beep/LED |

| | |
|--|--|
| | Did the MOST tester emit a tone or illuminate the LED? Yes Test passed. GO to A3. No Test failed. MOST tester or 2+0 harness fault |
|--|--|

A3: 2+4 INPUT/OUTPUT TEST

NOTES:

 2+4' indicates that the loop harness connector consists of 2 fibre optic terminals and 4 electrical terminals.

 The MOST tester may continue to emit a tone or illuminate the LED after the test switch is released. This does not indicate a fault.

- | | |
|----------|---|
| 1 | Set the MOST tester power switch to 'on' |
| 2 | Set the connector selector switch to '2+4' |
| 3 | Set the indication switch to 'beep' or 'LED' |
| 4 | Remove the covers from the MOST tester 2+4 connector and the 2+4 loop harness connector |
| 5 | Connect the 2+4 loop harness to the MOST tester 2+4 connector |
| 6 | Operate the test switch and check the MOST tester beep/LED |

| | |
|--|--|
| | Did the MOST tester emit a tone or illuminate the LED? Yes Test passed. GO to A4. No Test failed. MOST tester or 2+4 harness fault |
|--|--|

A4: ADAPTER HARNESS AND PRISM TEST

 NOTE: The MOST tester may continue to emit a tone or illuminate the LED after the test switch is released. This does not indicate a fault.

- | | |
|----------|---|
| 1 | Set the MOST tester power switch to 'on' |
| 2 | Set the connector selector switch to '2+0' |
| 3 | Set the indication switch to 'beep' or 'LED' |
| 4 | Remove the covers from the MOST tester 2+0 connector, the prism, and the adapter harness connectors |
| 5 | Connect the adapter harness to the MOST tester 2+0 connector |
| 6 | Connect the prism to the adapter harness |
| 7 | Operate the test switch and check the MOST tester beep/LED |

| | |
|--|--|
| | Did the MOST tester emit a tone or illuminate the LED? Yes Test passed No Test failed. MOST tester, adapter harness or prism fault |
|--|--|

PINPOINT TEST B : MOST NETWORK INITIAL TESTS

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS |
|--|-------------------------|
| B1: MOST NETWORK INITIAL TEST 1 | |



NOTE: When connecting the MOST tester, use the 2+0 or 2+4 socket as appropriate and set the connector selector switch to match the socket in use

| | | |
|--|----------|--|
| | 1 | Switch on the audio/video system |
| | 2 | Disconnect the MOST harness connector from a control module located after the touch screen display and before the information and entertainment control module |
| | 3 | Set the MOST tester power switch to 'on' |
| | 4 | Connect the MOST harness connector to the MOST tester |
| | 5 | Check the touch screen display for indication of a MOST network fault |
| | | Has the MOST network been restored? Yes The disconnected control module is causing the MOST network fault. GO to Pinpoint Test E . No The disconnected control module is not causing MOST network fault. GO to B2 . |
| B2: MOST NETWORK INITIAL TEST 2 | | |
| | 1 | Check the MOST tester beep/LED |
| | | Did the MOST tester emit a tone or illuminate the LED? Yes MOST signal received. The MOST network fault is located downstream of the MOST tester. GO to Pinpoint Test C . No MOST signal not received. The MOST network fault is located upstream of the MOST tester. Disconnect the MOST harness connector from the MOST tester and reconnect it to the control module. GO to Pinpoint Test D . |

PINPOINT TEST C : MOST NETWORK DOWNSTREAM TESTS

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS |
|---|--|
| C1: MOST NETWORK DOWNSTREAM TEST 1 | |
| | 1 Refer to the electrical circuit diagrams and identify the succeeding control module on the MOST network |
| | Is this control module the information and entertainment control module? Yes GO to Pinpoint Test E . No GO to C2 . |
| C2: MOST NETWORK DOWNSTREAM TEST 2 | |
| | 1 Disconnect the MOST harness connector |
| | 2 Direct the MOST harness connector at a suitable surface and check for the presence of red light |
| | Is red light present? Yes Disconnect the MOST harness connector from the MOST tester and reconnect it to the control module. GO to C3 . No The fault is in the MOST harness between the MOST tester and the disconnected MOST harness connector. Install a new MOST harness as necessary |

C3: MOST NETWORK DOWNSTREAM TEST 3



NOTE: When connecting the MOST tester, use the 2+0 or 2+4 socket as appropriate and set the connector selector switch to match the socket in use


| | | |
|--|----------|---|
| | 1 | Connect the succeeding MOST harness connector to the MOST tester |
| | 2 | Check the touch screen display for indication of a MOST network fault |
| | | Has the MOST network been restored? Yes The disconnected control module is causing the MOST network fault. GO to Pinpoint Test E . No The disconnected control module is not causing the MOST network fault. GO to C1 . |

PINPOINT TEST D : MOST NETWORK UPSTREAM TESTS

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS |
|---|--|
| D1: MOST NETWORK UPSTREAM TEST 1 | |
| | 1 Refer to the electrical circuit diagrams and identify the preceding control module on the MOST network |
| | Is this control module the touch screen display? Yes GO to Pinpoint Test G . No GO to D2 . |
| D2: MOST NETWORK UPSTREAM TEST 2 | |
| | 1 Disconnect the MOST harness connector from the control module |

| | |
|--|---|
| | 2 Direct the MOST harness connector at a suitable surface and check for the presence of red light |
| | Is red light present? Yes The MOST network fault is in the control module or the MOST harness to the succeeding control module. GO to D3. No The MOST network fault is located upstream of the disconnected control module. Reconnect the MOST harness connector to the control module. GO to D1. |

D3: MOST NETWORK UPSTREAM TEST 3

 NOTE: When connecting the MOST tester, use the 2+0 or 2+4 socket as appropriate and set the connector selector switch to match the socket in use

| | |
|--|--|
| | 1 Connect the MOST harness connector to the MOST tester |
| | 2 Check the touch screen display for indication of a MOST network fault |
| | Has the MOST network been restored? Yes The disconnected control module is causing the MOST network fault. GO to Pinpoint Test E. No The fault is in the MOST harness between the MOST tester and the succeeding control module. Install a new MOST harness as necessary |


PINPOINT TEST E : CONTROL MODULE TESTS

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS |
|-----------------|-------------------------|
|-----------------|-------------------------|

E1: CONTROL MODULE TEST 1

NOTES:

 When connecting the MOST tester, use the 2+0 or 2+4 socket as appropriate and set the connector selector switch to match the socket in use

 The MOST tester may continue to emit a tone or illuminate the LED after the test switch is released. This does not indicate a fault.

| | |
|--|--|
| | 1 Connect the MOST tester to the relevant control module using the adapter harness |
| | 2 Operate the test switch and check the MOST tester beep/LED |
| | Did the MOST tester emit a tone or illuminate the LED? Yes MOST signal received. Tests inconclusive. Reconnect the MOST harness connector to the control module and confirm that the MOST network fault is still present. Repeat the tests from the beginning. GO to Pinpoint Test B. No GO to E2. |

E2: CONTROL MODULE TEST 2

| | |
|--|---|
| | 1 Refer to the electrical circuit diagrams and test the relevant control module power and ground circuits for open circuit, high resistance |
| | Are the power and ground circuits within specification? Yes GO to E3. No Repair the power and/or ground circuit |

E3: CONTROL MODULE TEST 3

| | |
|--|---|
| | 1 Reconnect the MOST harness to the control module |
| | 2 Check the touch screen display for indication of a MOST network fault |
| | Has the MOST network been restored? Yes Tests inconclusive. Repeat the tests from the beginning. GO to Pinpoint Test B. No Install a new control module |

PINPOINT TEST F : MOST NETWORK FINAL DOWNSTREAM TEST

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS |
|-----------------|-------------------------|
|-----------------|-------------------------|

F1: MOST NETWORK FINAL DOWNSTREAM TEST 1

NOTES:

 When connecting the MOST tester, use the 2+0 or 2+4 socket as appropriate and set the connector selector switch to match the socket in use



The MOST tester may continue to emit a tone or illuminate the LED after the test switch is released. This does not indicate a fault.

| | | |
|---|------------|--|
| | 1 | Disconnect the MOST harness connector from the MOST tester |
| | 2 | Reconnect the MOST harness connector to the control module |
| | 3 | Disconnect the MOST harness connector from the information and entertainment control module |
| | 4 | Connect the MOST harness connector to the MOST tester |
| | 5 | Operate the test switch and check the MOST tester beep/LED |
| | | Did the MOST tester emit a tone or illuminate the LED? |
| | Yes | GO to F2. |
| | No | The fault is in the harness between the information and entertainment control module and the preceding control module. Install a new MOST harness as necessary |
| F2: MOST NETWORK FINAL DOWNSTREAM TEST 2 | | |
| | 1 | Disconnect the MOST harness connector from the MOST tester |
| | 2 | Reconnect the MOST harness connector to the information and entertainment control module |
| | 3 | Check the touch screen display for indication of a MOST network fault |
| | | Has the MOST network been restored? |
| | Yes | Tests inconclusive. Repeat the tests from the beginning. GO to Pinpoint Test B. |
| | No | Install a new information and entertainment control module |

PINPOINT TEST G : MOST NETWORK FINAL UPSTREAM TESTS

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS | |
|---|-------------------------|--|
| G1: MOST NETWORK FINAL UPSTREAM TEST 1 | | |
| | | NOTE: The MOST tester may continue to emit a tone or illuminate the LED after the test switch is released. This does not indicate a fault. |
| | 1 | Disconnect the MOST harness connector from the touch screen display |
| | 2 | Connect the MOST tester to the touch screen display using the adapter harness |
| | 3 | Operate the test switch and check the MOST tester beep/LED |
| | | Did the MOST tester emit a tone or illuminate the LED? |
| | Yes | The fault is in the MOST harness between the touch screen display and the succeeding control module. Install a new MOST harness as necessary |
| | No | GO to G2. |
| G2: MOST NETWORK FINAL UPSTREAM TEST 2 | | |
| | 1 | Reconnect the MOST harness to the touch screen display |
| | 2 | Check the touch screen display for indication of a MOST network fault |
| | | Has the MOST network been restored? |
| | Yes | Tests inconclusive. Repeat the tests from beginning. GO to Pinpoint Test B. |
| | No | Install a new touch screen display |

PINPOINT TEST H : BLANK SCREEN TESTS

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS | |
|--------------------------------|-------------------------|--|
| H1: BLANK SCREEN TEST 1 | | |
| | | NOTE: When connecting the MOST tester, use the 2+0 or 2+4 socket as appropriate and set the connector selector switch to match the socket in use |
| | 1 | Switch on the audio/video system |
| | 2 | Remove the cover from the MOST diagnostic connector |
| | 3 | Set the MOST tester power switch to 'on' |
| | 4 | Connect the MOST tester to the MOST diagnostic connector |
| | 5 | Check the touch screen display for indication of a MOST network fault |
| | | Has the MOST network been restored? |
| | Yes | The MOST diagnostic connector cover is causing the MOST network fault. GO to H2. |
| | No | The MOST diagnostic connector cover is not causing MOST network fault. GO to H3. |
| H2: BLANK SCREEN TEST 2 | | |

| | | |
|--------------------------------|----------|--|
| | 1 | Disconnect the MOST tester |
| | 2 | Install the cover to the MOST diagnostic connector |
| | | Has the MOST network been restored? Yes No further action required No Install a new MOST diagnostic connector cover |
| H3: BLANK SCREEN TEST 3 | | |
| | 1 | Check the MOST tester beep/LED |
| | | Did the MOST tester emit a tone or illuminate the LED? Yes MOST signal received. The MOST network fault is located downstream of the MOST tester. GO to H4. No MOST signal not received. The MOST network fault is located upstream of the MOST tester. Disconnect the MOST tester from the MOST diagnostic connector and install the cover. GO to H5. |
| H4: BLANK SCREEN TEST 4 | | |
| | 1 | Disconnect the MOST harness connector from the touch screen display |
| | 2 | Direct the MOST harness connector at a suitable surface and check for the presence of red light |
| | | Is red light present? Yes GO to Pinpoint Test J. No The fault is in the MOST harness between the MOST diagnostic connector and the touch screen display. Install a new MOST harness as necessary |
| H5: BLANK SCREEN TEST 5 | | |
| | 1 | Disconnect the MOST harness connector from the information and entertainment control module |
| | 2 | Direct the information and entertainment control module at a suitable surface and check for the presence of red light |
| | | Is red light present? Yes Install a new MOST harness between the information and entertainment control module and the MOST diagnostic connector No GO to Pinpoint Test L. |

PINPOINT TEST I : INFORMATION AND ENTERTAINMENT CONTROL MODULE TESTS

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS |
|--|---|
| I1: INFORMATION AND ENTERTAINMENT CONTROL MODULE TEST 1 | |
| | 1 Using the manufacturer approved diagnostic system, check the information and entertainment control module for related DTCs |
| | Is communication possible between the manufacturer approved diagnostic system and the information and entertainment control module? Yes Refer to the relevant DTC index No GO to I2. |
| I2: INFORMATION AND ENTERTAINMENT CONTROL MODULE TEST 2 | |
| | 1 Refer to the electrical circuit diagrams and test the information and entertainment control module power and ground circuits for open circuit, high resistance |
| | Are the power and ground circuits within specification? Yes GO to I3. No Repair the power and/or ground circuit |
| I3: INFORMATION AND ENTERTAINMENT CONTROL MODULE TEST 3 | |
| | 1 Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and test the medium speed CAN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance |
| | Is the medium speed CAN bus within specification? Yes Install a new information and entertainment control module No Repair the medium speed CAN bus circuit |

PINPOINT TEST J : TOUCH SCREEN DISPLAY TESTS

| TEST CONDITIONS | DETAILS/RESULTS/ACTIONS |
|--|---|
| J1: TOUCH SCREEN DISPLAY TEST 1 | |
| | 1 Refer to the electrical circuit diagrams and test the touch screen display power and ground circuits for open circuit, high resistance |

| | |
|--|---|
| | Are the power and ground circuits within specification? Yes GO to J2. No Repair the power and/or ground circuit |
| J2: TOUCH SCREEN DISPLAY TEST 2 | |
| 1 | Reconnect the MOST harness to the touch screen display |
| 2 | Check the touch screen display for indication of a MOST network fault |
| | Has the MOST network been restored? Yes Tests inconclusive. Repeat the tests from beginning. GO to Pinpoint Test B. No Install a new touch screen display |

DTC Index

Central Junction Box (CJB)

CAUTIONS:



Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle



When probing connectors to take measurements in the course of the pinpoint tests, use the adaptor kit, part number 3548-1358-00

NOTES:



If the control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the warranty policy and procedures manual (section B1.2), or determine if any prior approval programme is in operation, prior to the installation of a new module/component



Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system)



When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places and with a current calibration certificate. When testing resistance, always take the resistance of the digital multimeter leads into account



Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests



Inspect connectors for signs of water ingress, and pins for damage and/or corrosion



If diagnostic trouble codes are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals



Where an 'on demand self-test' is referred to, this can be accessed via the 'diagnostic trouble code monitor' tab on the manufacturers approved diagnostic system



Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required

| DTC | Description | Possible Cause | Action |
|---------|--|---|--|
| B00D511 | Restraint System Passenger Disable Indicator | <ul style="list-style-type: none"> PAD lamp supply circuit - short to ground | Refer to the electrical circuit diagrams and check PAD lamp supply circuit for short to ground |
| B00D512 | Restraint System Passenger Disable Indicator | <ul style="list-style-type: none"> PAD lamp supply circuit - short to power | Refer to the electrical circuit diagrams and check PAD lamp supply circuit for short to power |
| B00D513 | Restraint System Passenger Disable Indicator | <ul style="list-style-type: none"> PAD lamp supply circuit - open circuit | Refer to the electrical circuit diagrams and check PAD lamp supply circuit for open circuit |

| DTC | Description | Possible Cause | Action |
|------------|-------------------------------|--|---|
| B100951 | Ignition Authorisation | <ul style="list-style-type: none"> Faulty instrument cluster Target SID re-synchronisation error following programming CAN fault | Check ignition, power and ground supplies to CJB and instrument cluster. Re-synchronize ID by re-configuring the instrument cluster as a new module. Check CAN communications between instrument cluster and tester |
| B100962 | Ignition Authorisation | <ul style="list-style-type: none"> Low speed CAN fault CJB fault Instrument cluster fault Incorrect module installed (CJB/Instrument cluster) Target SID synchronisation error following re-programming Noise/EMC related error | Check CAN communications between CJB and instrument cluster. Check ignition, power and ground supplies to CJB and instrument cluster. Confirm correct module is installed. Re-synchronise ID by re-configuring the instrument cluster as a new module. Check CAN network for interference/EMC related issues |
| B100963 | Ignition Authorisation | <ul style="list-style-type: none"> CJB fault Low speed CAN fault Instrument cluster fault Low battery voltage <9V | Check Power and Ground supplies to CJB and instrument cluster. Check CAN communications between CJB and instrument cluster. Check battery is in fully charged and serviceable condition, refer to the battery care manual |
| B100964 | Ignition Authorisation | <ul style="list-style-type: none"> CJB fault Low speed CAN fault Instrument cluster fault | Check power and ground supplies to CJB and instrument cluster. Check CAN communications between CJB and instrument cluster |
| B102B67 | Passive Key | <ul style="list-style-type: none"> CJB fault Low speed CAN fault Remote Keyless Entry (RKE) module fault Write target SID synchronisation error following re-programming | Check power and ground supplies to CJB and RKE module. Check CAN communications between CJB and RKE module. Re-synchronise ID by re-configuring the RKE module as a new module |
| B102B87 | Passive Key | <ul style="list-style-type: none"> CJB fault Low speed CAN fault RKE module fault Key fob battery low/battery contact issue Interference from other RF signal EMC/noise Receiver fault Receiver not programmed correctly Serial communications fault (between receiver and RKE module) Key fault Passive antenna fault Confirm placement of key within vehicle | Check power and ground supplies to CJB, RKE module and receiver. Check CAN communications between CJB and instrument cluster. Check key fob battery. Confirm vehicle surroundings, move vehicle. Check CAN network for interference/EMC related issues. Disconnect battery, then re-connect - confirm operation by re-programming keys. Check serial circuit between receiver and RKE module. Confirm spare key works. Refer to the electrical circuit diagrams and test circuits to all 3 antennas. Check whereabouts of key |
| B108413 | Boot/Trunk Motor Close Switch | <ul style="list-style-type: none"> Trunk latch open signal circuit - open circuit | Refer to the electrical circuit diagrams and check trunk latch open signal circuit for open circuit |
| B108783 | LIN Bus "A" | <ul style="list-style-type: none"> Checksum of the received LIN frame from battery backed sounder, roof header console, and/or rain/light sensor is incorrect | Check operation of rain/light sensor by covering sensor or applying water to screen, install a new sensor as required |
| B108788 | LIN Bus "A" | <ul style="list-style-type: none"> Bus off. Battery backed sounder, roof header console, and/or rain/light sensor LIN circuit - short to ground, power | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check battery backed sounder, roof header console, and rain/light sensor LIN circuit for short to ground, power |
| B108A11 | Start Button | <ul style="list-style-type: none"> Start/Stop switch analogue input circuits 1 or 2 - short to ground | Refer to the electrical circuit diagrams and check Start/Stop switch analogue input circuits 1 and 2 for short to ground |

| DTC | Description | Possible Cause | Action |
|------------|-------------------------|--|---|
| B108A12 | Start Button | <ul style="list-style-type: none"> Start/Stop switch analogue input circuits 1 or 2 - short to power | Refer to the electrical circuit diagrams and check Start/Stop switch analogue input circuits 1 and 2 for short to power |
| B109512 | Wiper On/Off Relay | <ul style="list-style-type: none"> Wiper On/Off relay control circuit - short to power | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check wiper On/Off relay control circuit for short to power |
| B109514 | Wiper On/Off Relay | <ul style="list-style-type: none"> Wiper On/Off relay control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check wiper On/Off relay control circuit for short to ground, open circuit |
| B109612 | Wiper High/Low Relay | <ul style="list-style-type: none"> Wiper Fast/Slow relay control circuit - short to power | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check wiper Fast/Slow relay control circuit for short to power |
| B109614 | Wiper High/Low Relay | <ul style="list-style-type: none"> Wiper Fast/Slow relay control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check wiper Fast/Slow relay control circuit for short to ground, open circuit |
| B109712 | Heated Windshield Relay | <ul style="list-style-type: none"> Heated windshield relay control circuit - short to power | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check heated windshield relay control circuit for short to power |
| B109714 | Heated Windshield Relay | <ul style="list-style-type: none"> Heated windshield relay control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check heated windshield relay control circuit for short to ground, open circuit |
| B10A612 | Main Light Switch | <ul style="list-style-type: none"> Master light switch signal from roof header console circuit - short to power | Refer to the electrical circuit diagrams and check master light switch signal from roof header console circuit for short to power |
| B10A623 | Main Light Switch | <ul style="list-style-type: none"> Master light switch signal from roof header console signal stuck low. Switch is read as ON for too long a time | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check master light switch signal from roof header console for short to ground |
| B10AD09 | Rain Sensor | <ul style="list-style-type: none"> Component failures | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Suspect the rain/light sensor, check and install a new sensor as required |
| B10AD11 | Rain Sensor | <ul style="list-style-type: none"> Rain/light sensor power circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check rain/light sensor power circuit for short to ground |
| B10AD96 | Rain Sensor | <ul style="list-style-type: none"> Component internal failure | Suspect the rain/light sensor, check and install a new sensor as required |
| B10E511 | PCM Wake-up Signal | <ul style="list-style-type: none"> ECM wake-up signal circuit - short to ground | Refer to the electrical circuit diagrams and check ECM wake-up signal circuit for short to ground |
| B10E512 | PCM Wake-up Signal | <ul style="list-style-type: none"> ECM wake-up signal circuit - short to power | Refer to the electrical circuit diagrams and check ECM wake-up signal circuit for short to power |
| B10E513 | PCM Wake-up Signal | <ul style="list-style-type: none"> ECM wake-up signal circuit - open circuit | Refer to the electrical circuit diagrams and check ECM wake-up signal circuit for open circuit |
| B10F111 | Key In Switch | <ul style="list-style-type: none"> Keyless vehicle module, key IN status circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check keyless vehicle module, key IN status circuit for short to ground |
| B10F112 | Key In Switch | <ul style="list-style-type: none"> Keyless vehicle module, key IN status circuit - short to power | Refer to the electrical circuit diagrams and check keyless vehicle module, key IN status circuit for short to power |
| B10F113 | Key In Switch | <ul style="list-style-type: none"> Keyless vehicle module, key IN status circuit - open circuit | Refer to the electrical circuit diagrams and check keyless vehicle module, key IN status circuit for open circuit |



| DTC | Description | Possible Cause | Action |
|------------|----------------------------|--|--|
| B10F211 | Sunroof Control | <ul style="list-style-type: none"> Sunroof enable signal circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check sunroof enable signal circuit for short to ground |
| B10F212 | Sunroof Control | <ul style="list-style-type: none"> Sunroof enable signal circuit - short to power | Refer to the electrical circuit diagrams and check sunroof enable signal circuit for short to power |
| B10F213 | Sunroof Control | <ul style="list-style-type: none"> Sunroof enable signal circuit - open circuit | Refer to the electrical circuit diagrams and check sunroof enable signal circuit for open circuit |
| B10F311 | Left Front Position Light | <ul style="list-style-type: none"> Left front side lamps circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check left front side lamps circuit for short to ground |
| B10F315 | Left Front Position Light | <ul style="list-style-type: none"> Left front side lamps circuit - short to power, open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check left front side lamps circuit for short to power, open circuit |
| B10F411 | Right Front Position Light | <ul style="list-style-type: none"> Right front side lamps circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check right front side lamps circuit for short to ground |
| B10F415 | Right Front Position Light | <ul style="list-style-type: none"> Right front side lamps circuit - short to power, open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check right front side lamps circuit for short to power, open circuit |
| B10F812 | Accessory socket 'A' relay | <ul style="list-style-type: none"> Accessory socket 'A' relay control circuit - short to power | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check accessory socket 'A' relay control circuit for short to power |
| B10F814 | Accessory socket 'A' relay | <ul style="list-style-type: none"> Accessory socket 'A' relay control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check accessory socket 'A' relay control circuit for short to ground, open circuit |
| B10F912 | Accessory socket 'B' relay | <ul style="list-style-type: none"> Front powerpoint, trailer tow connector, road pricing connector, sunblind power supply circuits - short to power | Refer to the electrical circuit diagrams and check front powerpoint, trailer tow connector, road pricing connector, sunblind power supply circuits for short to power |
| B10F914 | Accessory socket 'B' relay | <ul style="list-style-type: none"> Front powerpoint, trailer tow connector, road pricing connector, sunblind power supply circuits - short to ground, open circuit | Refer to the electrical circuit diagrams and check front powerpoint, trailer tow connector, road pricing connector, sunblind power supply circuits for short to ground, open circuit |
| B10F993 | Accessory socket 'B' relay | <ul style="list-style-type: none"> Front powerpoint, trailer tow connector, road pricing connector, sunblind power supply circuits - short to power, ground, open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check front powerpoint, trailer tow connector, road pricing connector, sunblind power supply circuits for short to power, ground, open circuit |
| B10FA93 | Delayed Power Off relay | <ul style="list-style-type: none"> ADRC ECM, roof header console lamp, glove box lamp, RH/LH footwell lamps, JAG Sense glove box module, RH/LH sunvisor lamps, rear dome lamps switched power circuits - short to power, open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check ADRC ECM, roof header console lamp, glove box lamp, RH/LH footwell lamps, JAG Sense glove box module, RH/LH sunvisor lamps, rear dome lamps switched power circuits for short to power, open circuit |
| B10FF11 | Ignition control | <ul style="list-style-type: none"> ECM and FPDB ignition control circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check ECM and FPDB ignition control circuit for short to ground |
| B10FF13 | Ignition control | <ul style="list-style-type: none"> ECM and FPDB ignition control circuit - open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check ECM and FPDB ignition control circuit for open circuit |

| DTC | Description | Possible Cause | Action |
|------------|------------------------------------|--|---|
| B110011 | O2 sensor heater relay | <ul style="list-style-type: none"> FPDB O2 sensor heater relay control circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check FPDB O2 sensor heater relay control circuit for short to ground |
| B113D12 | Sunroof Global Open/Close Control | <ul style="list-style-type: none"> Roof opening panel global open/close control circuit - short to power | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check roof opening panel global open/close control circuit for short to power |
| B113D14 | Sunroof Global Open/Close Control | <ul style="list-style-type: none"> Roof opening panel global open/close control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check roof opening panel global open/close control circuit for short to ground, open circuit |
| B114011 | Engine Crank Authorisation | <ul style="list-style-type: none"> Engine crank authorisation signal circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check engine crank authorisation signal circuit for short to ground |
| B114211 | Ignition Status 1 | <ul style="list-style-type: none"> Ignition supply 1 circuits - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check all ignition supply 1 circuits for short to ground |
| B114311 | Ignition Status 2 | <ul style="list-style-type: none"> Ignition supply 2 circuits - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check all ignition supply 2 circuits for short to ground |
| B114411 | Heated Steering Wheel Supply | <ul style="list-style-type: none"> Heated steering wheel supply circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check heated steering wheel supply circuit for short to ground |
| B114511 | Glovebox Locking Motor | <ul style="list-style-type: none"> Glovebox latch locking motor circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check glovebox latch locking motor circuit for short to ground |
| B114512 | Glovebox Locking Motor | <ul style="list-style-type: none"> Glovebox latch locking motor control circuit - short to power | Refer to the electrical circuit diagrams and check glovebox latch locking motor control circuit for short to power |
| B114513 | Glovebox Locking Motor | <ul style="list-style-type: none"> Glovebox latch locking motor control circuit - open circuit | Refer to the electrical circuit diagrams and check glovebox latch locking motor control circuit for open circuit |
| B114612 | Passive sounder Supply | <ul style="list-style-type: none"> Security passive sounder control circuit - short to power | Refer to the electrical circuit diagrams and check security passive sounder control circuit for short to power |
| B114614 | Passive sounder Supply | <ul style="list-style-type: none"> Security passive sounder control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check security passive sounder control circuit for short to ground, open circuit |
| B115811 | Front Passenger Seat Heater Sensor | <ul style="list-style-type: none"> Front passenger seat heater sensor circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check front passenger seat heater sensor circuit for short to ground |
| B115813 | Front Passenger Seat Heater Sensor | <ul style="list-style-type: none"> Front passenger seat heater sensor circuit - open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check front passenger seat heater sensor circuit for open circuit |
| B115911 | Driver Seat Heater Sensor | <ul style="list-style-type: none"> Driver seat heater sensor circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check driver seat heater sensor circuit for short to ground |
| B115913 | Driver Seat Heater Sensor | <ul style="list-style-type: none"> Driver seat heater sensor circuit - open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check driver seat heater sensor circuit for open circuit |
| B115A11 | Front Passenger Seat Heater | <ul style="list-style-type: none"> Front passenger seat heater supply circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check front passenger seat heater supply circuit for short to ground |
| B115A15 | Front Passenger Seat Heater | <ul style="list-style-type: none"> Front passenger seat heater supply circuit - short to power, open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check front passenger seat heater supply circuit for short to power, open circuit |

| DTC | Description | Possible Cause | Action |
|------------|--------------------------------------|---|---|
| B115B11 | Driver Seat Heater | <ul style="list-style-type: none"> Driver seat heater supply circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check driver seat heater supply circuit for short to ground |
| B115B15 | Driver Seat Heater | <ul style="list-style-type: none"> Driver seat heater supply circuit - short to power, open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check driver seat heater supply circuit for short to power, open circuit |
| B117513 | Driver Door Ajar Switch | <ul style="list-style-type: none"> Driver door ajar switch signal circuit - open circuit | Refer to the electrical circuit diagrams and check driver door ajar switch signal circuit for open circuit |
| B117613 | Passenger Door Ajar Switch | <ul style="list-style-type: none"> Passenger door ajar switch signal circuit - open circuit | Refer to the electrical circuit diagrams and check passenger door ajar switch signal circuit for open circuit |
| B117712 | Screenwash Level Switch | <ul style="list-style-type: none"> Screenwash level switch signal circuit - short to power | Refer to the electrical circuit diagrams and check screenwash level switch signal circuit for short to power |
| B11C013 | Driver Side Rear Door Ajar Switch | <ul style="list-style-type: none"> Left rear door ajar switch signal circuit - open circuit | Refer to the electrical circuit diagrams and check left rear door ajar switch signal circuit for open circuit |
| B11C113 | Passenger Side Rear Door Ajar Switch | <ul style="list-style-type: none"> Right rear door ajar switch signal circuit - open circuit | Refer to the electrical circuit diagrams and check right rear door ajar switch signal circuit for open circuit |
| B122223 | Master Lock/Unlock Switch | <ul style="list-style-type: none"> Master lock or unlock switch digital input circuit - signal stuck low | Refer to the electrical circuit diagrams and check master lock and unlock switch digital input circuits for short to ground, open circuit |
| B123711 | Gear Shift Module Early Wake-up | <ul style="list-style-type: none"> Transmission shift module wake-up control circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check transmission shift module wake-up control circuit for short to ground |
| B123712 | Gear Shift Module Early Wake-up | <ul style="list-style-type: none"> Transmission shift module wake-up control circuit - short to power | Refer to the electrical circuit diagrams and check transmission shift module wake-up control circuit for short to power |
| B123713 | Gear Shift Module Early Wake-up | <ul style="list-style-type: none"> Transmission shift module wake-up control circuit - open circuit | Refer to the electrical circuit diagrams and check transmission shift module wake-up control circuit for open circuit |
| B123E13 | Crank Enable | <ul style="list-style-type: none"> OK to crank signal circuit - open circuit | Refer to the electrical circuit diagrams and check OK to crank signal circuit for open circuit |
| B1A8596 | Ambient Light Sensor | <ul style="list-style-type: none"> Light sensor internal electronic failure | Check and install a new sensor as required |
| B1C4513 | Front Wiper Park Position Switch | <ul style="list-style-type: none"> Windshield wiper motor park switch signal circuit - open circuit | Refer to the electrical circuit diagrams and check windshield wiper motor park switch signal circuit for open circuit |
| B1C4523 | Front Wiper Park Position Switch | <ul style="list-style-type: none"> Signal stuck low | Refer to the electrical circuit diagrams and check front wiper park position switch input circuit for short, open circuit |
| B1C7812 | Powerwash Relay | <ul style="list-style-type: none"> Powerwash relay control circuit - short to power | Refer to the electrical circuit diagrams and check powerwash relay control circuit for short to power |
| B1C7814 | Powerwash Relay | <ul style="list-style-type: none"> Powerwash relay control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check powerwash relay control circuit for short to ground, open circuit |
| B1C7911 | Front Washer Pump | <ul style="list-style-type: none"> Screenwash pump control circuit - short to ground | Refer to the electrical circuit diagrams and check screenwash pump control circuit for short to ground |

| DTC | Description | Possible Cause | Action |
|------------|---------------------------|---|--|
| B1C7913 | Front Washer Pump | <ul style="list-style-type: none"> Screenwash pump control circuit - open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check screenwash pump control circuit for open circuit |
| B1C9812 | Left Corner Lamp Circuit | <ul style="list-style-type: none"> Left front corner lamp control circuit - short to power | Refer to the electrical circuit diagrams and check left front corner lamp control circuit for short to power |
| B1C9814 | Left Corner Lamp Circuit | <ul style="list-style-type: none"> Left front corner lamp control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check left front corner lamp control circuit for short to ground, open circuit |
| B1C9912 | Right Corner Lamp Circuit | <ul style="list-style-type: none"> Right front corner lamp control circuit - short to power | Refer to the electrical circuit diagrams and check right front corner lamp control circuit for short to power |
| B1C9914 | Right Corner Lamp Circuit | <ul style="list-style-type: none"> Right front corner lamp control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check right front corner lamp control circuit for short to ground, open circuit |
| B1D0011 | Left Low Beam | <ul style="list-style-type: none"> Left dip beam control circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check left dip beam control circuit for short to ground |
| B1D0012 | Left Low Beam | <ul style="list-style-type: none"> Left dip beam control circuit - short to power | Refer to the electrical circuit diagrams and check left dip beam control circuit for short to power |
| B1D0013 | Left Low Beam | <ul style="list-style-type: none"> Left dip beam control circuit - open circuit | Refer to the electrical circuit diagrams and check left dip beam control circuit for open circuit |
| B1D0111 | Right Low Beam | <ul style="list-style-type: none"> Right dip beam control circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check right dip beam control circuit for short to ground |
| B1D0112 | Right Low Beam | <ul style="list-style-type: none"> Right dip beam control circuit - short to power | Refer to the electrical circuit diagrams and check right dip beam control circuit for short to power |
| B1D0113 | Right Low Beam | <ul style="list-style-type: none"> Right dip beam control circuit - open circuit | Refer to the electrical circuit diagrams and check right dip beam control circuit for open circuit |
| B1D0211 | Left High Beam Circuit | <ul style="list-style-type: none"> Left high beam control circuit - short to ground | Refer to the electrical circuit diagrams and check left high beam control circuit for short to ground |
| B1D0212 | Left High Beam Circuit | <ul style="list-style-type: none"> Left high beam control circuit - short to power | Refer to the electrical circuit diagrams and check left high beam control circuit for short to power |
| B1D0213 | Left High Beam Circuit | <ul style="list-style-type: none"> Left high beam control circuit - open circuit | Refer to the electrical circuit diagrams and check left high beam control circuit for open circuit |
| B1D0311 | Right High Beam Circuit | <ul style="list-style-type: none"> Right high beam control circuit - short to ground | Refer to the electrical circuit diagrams and check right high beam control circuit for short to ground |
| B1D0312 | Right High Beam Circuit | <ul style="list-style-type: none"> Right high beam control circuit - short to power | Refer to the electrical circuit diagrams and check right high beam control circuit for short to power |
| B1D0313 | Right High Beam Circuit | <ul style="list-style-type: none"> Right high beam control circuit - open circuit | Refer to the electrical circuit diagrams and check right high beam control circuit for open circuit |
| B1D1711 | Battery Backed Sounder | <ul style="list-style-type: none"> Battery backed sounder inclination sensor control circuit - short to ground | Refer to the electrical circuit diagrams and check battery backed sounder inclination sensor control circuit for short to ground |
| B1D1811 | Volumetric Sensor | <ul style="list-style-type: none"> Intrusion sensor module supply circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check intrusion sensor module supply circuit for short to ground |

| DTC | Description | Possible Cause | Action |
|------------|---|--|--|
| B1D2711 | Heater Coolant Pump | <ul style="list-style-type: none"> Heater coolant pump control circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check heater coolant pump control circuit for short to ground |
| B1D2713 | Heater Coolant Pump | <ul style="list-style-type: none"> Heater coolant pump control circuit - open circuit | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check heater coolant pump control circuit for open circuit |
| B1D9796 | Tilt Sensor | <ul style="list-style-type: none"> Component internal failure | Suspect the battery backed sounder, check and install a new battery backed sounder as required |
| P057112 | Brake Switch A Circuit | <ul style="list-style-type: none"> Footbrake switch circuit - short to power | Refer to the electrical circuit diagrams and check footbrake switch circuit for short to power |
| P080111 | Reverse Inhibit Control Circuit | <ul style="list-style-type: none"> Electrochromic rear view mirror, reverse inhibit circuit - short to ground | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check electrochromic rear view mirror, reverse inhibit circuit for short to ground |
| P080112 | Reverse Inhibit Control Circuit | <ul style="list-style-type: none"> Electrochromic rear view mirror, reverse inhibit circuit - short to power | Refer to the electrical circuit diagrams and check electrochromic rear view mirror, reverse inhibit circuit for short to power |
| P080113 | Reverse Inhibit Control Circuit | <ul style="list-style-type: none"> Electrochromic rear view mirror, reverse inhibit circuit - open circuit | Refer to the electrical circuit diagrams and check electrochromic rear view mirror, reverse inhibit circuit for open circuit |
| P085013 | Park/Neutral Switch Input Circuit | <ul style="list-style-type: none"> Park/Neutral signal circuit - open circuit | Refer to the electrical circuit diagrams and check Park/Neutral signal circuit for open circuit |
| P162413 | Anti-theft System | <ul style="list-style-type: none"> RJB anti-theft signal circuit - open circuit | Refer to the electrical circuit diagrams and check RJB anti-theft signal circuit for open circuit |
| P254F13 | Engine Hood Switch Circuit/Open | <ul style="list-style-type: none"> Hood ajar switch signal circuit - open circuit | Refer to the electrical circuit diagrams and check hood ajar switch signal circuit for open circuit |
| U001988 | Low Speed CAN Communication Bus | <ul style="list-style-type: none"> Bus OFF | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |
| U014200 | Lost Communication With Body Control Module "B" | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |
| U015500 | Lost Communication With Instrument Panel Cluster (IPC) Control Module | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |
| U015600 | Lost Communication With Information Center "A" | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |
| U016400 | Lost Communication With HVAC Control Module | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |
| U016800 | Lost Communication With Vehicle Security Control Module | <ul style="list-style-type: none"> No sub type information | Check power and ground supplies to vehicle security module |
| U019900 | Lost Communication With "Door Control Module A" | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |
| U020000 | Lost Communication With "Door Control Module B" | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |

| DTC | Description | Possible Cause | Action |
|----------|--|---|---|
| U021400 | Lost Communication With Remote Function Actuation | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |
| U023100 | Lost Communication With Rain Sensing Module | <ul style="list-style-type: none"> No sub type information | Check power and ground supplies to rain sensing module. LIN circuit fault |
| U030000 | Internal Control Module Software Incompatibility | <ul style="list-style-type: none"> No sub type information | Suspect the CJB. Check and install a new CJB as required, refer to the new module/component installation note at the top of the DTC Index |
| U1000-00 | Solid State Driver Protection Active - Driver Disabled - No sub type information | <ul style="list-style-type: none"> Central junction box output circuit - Short circuit to ground, short circuit to power |  <p>NOTE: The relevant output is disabled while this DTC is set. Do not clear the DTC until the fault has been rectified</p> <ul style="list-style-type: none"> Using the manufacturer approved diagnostic system, check for other central junction box short circuit to ground and/or short circuit to power DTCs and refer to the relevant DTC index for corrective actions Once circuit faults have been rectified, clear DTC and retest |
| U1A1449 | CAN Initialisation Failure | <ul style="list-style-type: none"> Internal electronic failure | Suspect the CJB. Check and install a new CJB as required, refer to the new module/component installation note at the top of the DTC Index |
| U200813 | Sensor Cluster | <ul style="list-style-type: none"> Instrument cluster security signal circuit - open circuit | Refer to the electrical circuit diagrams and check instrument cluster security signal circuit for open circuit |
| U201012 | Switch Illumination | <ul style="list-style-type: none"> Switch/interior illumination PWM supply circuit - short to power | Refer to the electrical circuit diagrams and check switch/interior illumination PWM supply circuit for short to power |
| U201014 | Switch Illumination | <ul style="list-style-type: none"> Switch/interior illumination PWM supply circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check switch/interior illumination PWM supply circuit for short to ground, open circuit |
| U210000 | Initial Configuration Not Complete | <ul style="list-style-type: none"> RJB configuration (parameters) failure | Re-configure the RJB using the manufacturer approved diagnostic system |
| U3000-49 | Control Module - Internal electronic failure | <ul style="list-style-type: none"> Central junction box - Internal failure |  <p>NOTE: The relevant output is disabled while this DTC is set</p> <ul style="list-style-type: none"> Using the manufacturer approved diagnostic system, check for other central junction box short circuit to ground and/or short circuit to power DTCs and refer to the relevant DTC index for corrective actions Install a new central junction box as required. Clear DTCs and retest |
| U300055 | Control Module | <ul style="list-style-type: none"> Not configured | Re-configure the RJB using the manufacturer approved diagnostic system. Check the correct CJB is installed to vehicle market/specification. Install a new/correct CJB as required, refer to the new module/component installation note at the top of the DTC Index |
| U300087 | Control Module | <ul style="list-style-type: none"> Missing message | Carry out CAN network integrity test using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check CAN network between RJB and CJB for short, open circuit. Check RJB and then CJB for related DTCs and refer to the relevant DTC Index |
| U300281 | Vehicle Identification Number | <ul style="list-style-type: none"> Invalid serial data received | Suspect the CJB has previously been installed to another vehicle. Check and install the original or a new CJB |
| U300317 | Battery Voltage | <ul style="list-style-type: none"> Circuit voltage above threshold | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |

| DTC | Description | Possible Cause | Action |
|---------|-----------------|---|--|
| U300362 | Battery Voltage | <ul style="list-style-type: none"> Mis-match in battery voltage, of 2 volts or more, between CJB and RJB | Carry out any pinpoint tests associated with this DTC using the manufacturer approved diagnostic system. |

Rear Junction Box (RJB)

CAUTIONS:



Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle



When probing connectors to take measurements in the course of the pinpoint tests, use the adaptor kit, part number 3548-1358-00

NOTES:



If the control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the warranty policy and procedures manual (section B1.2), or determine if any prior approval programme is in operation, prior to the installation of a new module/component



Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system)



When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places and with a current calibration certificate. When testing resistance, always take the resistance of the digital multimeter leads into account



Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests



Inspect connectors for signs of water ingress, and pins for damage and/or corrosion



If diagnostic trouble codes are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals



Where an 'on demand self-test' is referred to, this can be accessed via the 'diagnostic trouble code monitor' tab on the manufacturers approved diagnostic system



Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required

| DTC | Description | Possible Causes | Action |
|---------|--|---|--|
| P046011 | Fuel Level Sensor A Circuit | <ul style="list-style-type: none"> Fuel level sensor A analogue input circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check fuel level sensor A analogue input circuit for short to ground |
| P046015 | Fuel Level Sensor A Circuit | <ul style="list-style-type: none"> Fuel level sensor A analogue input circuit - short to power, open circuit | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check fuel level sensor A analogue input circuit for short to power, open circuit |
| P057112 | Brake Switch A Circuit | <ul style="list-style-type: none"> Footbrake switch digital input signal circuits - short to power | Refer to the electrical circuit diagrams and check footbrake switch digital input signal circuits for short to power |
| P123012 | Fuel Pump Low Speed Malfunction (VLCM) | <ul style="list-style-type: none"> High Side output not driven - Diagnosis feedback indicates output is short to power | Refer to the electrical circuit diagrams and check fuel pump delivery module for short to power |

| DTC | Description | Possible Causes | Action |
|------------|---|---|--|
| P123014 | Fuel Pump Low Speed Malfunction (VLCM) | <ul style="list-style-type: none"> High Side output not driven - Diagnosis feedback indicates output is short to ground, open circuit | Refer to the electrical circuit diagrams and check fuel pump delivery module for short to ground, open circuit |
| P123093 | Fuel Pump Low Speed Malfunction (VLCM) | <ul style="list-style-type: none"> High Side output not driven - Diagnosis feedback indicates output is at open load or short to power | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check fuel pump delivery module for short to power, open circuit |
| P134611 | Fuel Level Sensor B Circuit | <ul style="list-style-type: none"> Fuel level sensor B analogue input circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check fuel level sensor B analogue input circuit for short to ground |
| P134615 | Fuel Level Sensor B Circuit | <ul style="list-style-type: none"> Fuel level sensor B analogue input circuit - short to power, open circuit | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check fuel level sensor B analogue input circuit for short to power, open circuit |
| P162413 | Anti-theft System | <ul style="list-style-type: none"> Anti-theft signal circuit from CJB - open circuit | Refer to the electrical circuit diagrams and check anti-theft signal circuit from CJB for open circuit |
| C111A11 | Right Stop Lamp | <ul style="list-style-type: none"> Right stop lamp control circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check right stop lamp control circuit for short to ground |
| C111A12 | Right Stop Lamp | <ul style="list-style-type: none"> Right stop lamp control circuit - short to power | Refer to the electrical circuit diagrams and check right stop lamp control circuit for short to power |
| C111A13 | Right Stop Lamp | <ul style="list-style-type: none"> Right stop lamp control circuit - open circuit | Refer to the electrical circuit diagrams and check right stop lamp control circuit for open circuit |
| C111B11 | Left Stop Lamp | <ul style="list-style-type: none"> Left stop lamp control circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check left stop lamp control circuit for short to ground |
| C111B13 | Left Stop Lamp | <ul style="list-style-type: none"> Left stop lamp control circuit - open circuit | Refer to the electrical circuit diagrams and check left stop lamp control circuit for open circuit |
| C112011 | Reversing lamp | <ul style="list-style-type: none"> Reverse lamp control circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check reverse lamp control circuit for short to ground |
| C112012 | Reversing lamp | <ul style="list-style-type: none"> Reverse lamp control circuit - short to power | Refer to the electrical circuit diagrams and check reverse lamp control circuit for short to power |
| C112013 | Reversing lamp | <ul style="list-style-type: none"> Reverse lamp control circuit - open circuit | Refer to the electrical circuit diagrams and check reverse lamp control circuit for open circuit |
| C1120-15 | Reversing lamp - circuit short to battery or open | <ul style="list-style-type: none"> Reverse lamp control circuit - short circuit to power, open circuit, high resistance | <ul style="list-style-type: none"> Refer to the electrical circuit diagrams and check reverse lamp control circuit for short circuit to power, open circuit, high resistance. Repair wiring harness as required. Clear DTC and retest |
| B100A51 | Fuel Pump Authorisation | <ul style="list-style-type: none"> RJB fault Low speed CAN fault Instrument cluster fault | Check power and ground supplies to RJB. Check CAN communications between RJB and instrument cluster. Check power and ground supplies to instrument cluster |
| B100A62 | Fuel Pump Authorisation | <ul style="list-style-type: none"> Low speed CAN fault RJB fault Instrument cluster fault Incorrect module installed (RJB/Instrument cluster) | Check CAN communications between RJB and instrument cluster. Check power and ground supplies to RJB and instrument cluster. Confirm correct module installed. Re-synchronise ID by re-configuring the RJB as a new module. Check CAN network for interference/EMC related issues |

| DTC | Description | Possible Causes | Action |
|------------|-------------------------|--|--|
| | | <ul style="list-style-type: none"> • Write target SID synchronisation error following re-programming • Noise/EMC related error | |
| B100A63 | Fuel Pump Authorisation | <ul style="list-style-type: none"> • RJB fault • Low speed CAN fault • Instrument cluster fault • Low battery voltage <9V | Check power and ground supplies to RJB and instrument cluster. Check CAN communications between RJB and instrument cluster. Check battery is in fully charged and serviceable condition, refer to the battery care manual |
| B102612 | Steering Column Lock | <ul style="list-style-type: none"> • Steering column lock ground circuit - short to power | Refer to the electrical circuit diagrams and check steering column lock ground circuit for short to power |
| B108783 | LIN Bus "A" | <ul style="list-style-type: none"> • The checksum of the received LIN frame is incorrect | Check the battery monitoring system and rear parking aid system for DTCs and refer to relevant DTC Index |
| B108786 | LIN Bus "A" | <ul style="list-style-type: none"> • The header of the LIN message received is incorrect | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Check the battery monitoring system and rear parking aid system for DTCs and refer to relevant DTC Index |
| B108788 | LIN Bus "A" | <ul style="list-style-type: none"> • Battery monitoring system LIN circuit - short to ground, power | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check battery monitoring system LIN circuit for short to ground, power |
| B108A23 | Start Button | <ul style="list-style-type: none"> • Start/Stop switch digital input signal circuit - stuck low | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check Start/Stop switch digital input signal circuit for short to ground |
| B10A111 | Trailer Tow Detection | <ul style="list-style-type: none"> • Trailer tow detection digital input circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check trailer tow detection digital input circuit for short to ground |
| B10AF12 | Blower Fan Relay | <ul style="list-style-type: none"> • High Side output not driven - Diagnosis feedback indicates output is short to power | Refer to the electrical circuit diagrams and check blower motor supply circuit for short to power |
| B10AF14 | Blower Fan Relay | <ul style="list-style-type: none"> • High Side output not driven - Diagnosis feedback indicates output is short to ground, open circuit | Refer to the electrical circuit diagrams and check blower motor supply circuit for short to ground, open circuit |
| B10AF93 | Blower Fan Relay | <ul style="list-style-type: none"> • High Side output not driven - Diagnosis feedback indicates output is at open load or short to power | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check blower motor supply circuit for short to power, open circuit |
| B10DD11 | Airbag Deployed | <ul style="list-style-type: none"> • Airbag deployed digital input signal circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check airbag deployed digital input signal circuit for short to ground |
| B10DD15 | Airbag Deployed | <ul style="list-style-type: none"> • Airbag deployed digital input signal circuit - short to power, open circuit | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check airbag deployed digital input signal circuit for short to power, open circuit |
| B10DD38 | Airbag Deployed | <ul style="list-style-type: none"> • Signal frequency incorrect | Check the RCM for related DTCs and refer to the relevant DTC Index |
| B10DE11 | Low Fuel Warning Switch | <ul style="list-style-type: none"> • Diesel run-dry switch analogue input circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check diesel run-dry switch analogue input circuit for short to ground |

| DTC | Description | Possible Causes | Action |
|------------|---|--|--|
| B10DE15 | Low Fuel Warning Switch | <ul style="list-style-type: none"> • Diesel run-dry switch analogue input circuit - short to power, open circuit | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check diesel run-dry switch analogue input circuit for short to power, open circuit |
| B111211 | Park Aid Ignition | <ul style="list-style-type: none"> • Parking aid ignition supply circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check parking aid ignition supply circuit for short to ground |
| B111212 | Park Aid Ignition | <ul style="list-style-type: none"> • Parking aid ignition supply circuit - short to power | Refer to the electrical circuit diagrams and check parking aid ignition supply circuit for short to power |
| B111511 | High Mounted Stop Lamp Control | <ul style="list-style-type: none"> • High mounted stop lamp control circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check high mounted stop lamp control circuit for short to ground |
| B111611 | Left Tail Lamp | <ul style="list-style-type: none"> • Left hand tail lamp control circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check left hand tail lamp control circuit for short to ground |
| B111711 | Right Tail Lamp | <ul style="list-style-type: none"> • Right hand tail lamp control circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check right hand tail lamp control circuit for short to ground |
| B111A11 | Number Plate Lamps | <ul style="list-style-type: none"> • Right hand or left hand number plate lamp control circuits - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check right hand and left hand number plate lamp control circuits for short to ground |
| B111A12 | Number Plate Lamps | <ul style="list-style-type: none"> • Right hand or left hand number plate lamp control circuits - short to power | Refer to the electrical circuit diagrams and check right hand and left hand number plate lamp control circuits for short to power |
| B111A13 | Number Plate Lamps | <ul style="list-style-type: none"> • Right hand or left hand number plate lamp control circuits - open circuit | Refer to the electrical circuit diagrams and check right hand and left hand number plate lamp control circuits for open circuit |
| B111A-15 | Number Plate Lamps - circuit short to battery or open | <ul style="list-style-type: none"> • Right or left side licence plate lamp(s) inoperative • Right or left side licence plate lamp control circuits - short circuit to power, open circuit, high resistance | <ul style="list-style-type: none"> • Refer to the electrical circuit diagrams and check right side and left side licence plate lamp control circuits for short circuit to power, open circuit, high resistance. Repair wiring harness as required. Clear DTC and retest |
| B111D12 | Boot/Trunk Motor Open | <ul style="list-style-type: none"> • Luggage compartment lid latch actuator control circuit - short to power | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check luggage compartment lid latch actuator control circuit for short to power |
| B111D14 | Boot/Trunk Motor Open | <ul style="list-style-type: none"> • Luggage compartment lid latch actuator control circuit - short to ground, open circuit | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check luggage compartment lid latch actuator control circuit for short to ground, open circuit |
| B111E11 | Boot/Trunk Lamps | <ul style="list-style-type: none"> • Luggage compartment lamp control circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check luggage compartment lamp control circuit for short to ground |
| B111E12 | Boot/Trunk Lamps | <ul style="list-style-type: none"> • Luggage compartment lamp control circuit - short to power | Refer to the electrical circuit diagrams and check luggage compartment lamp control circuit for short to power |

| DTC | Description | Possible Causes | Action |
|------------|---|--|--|
| B111E13 | Boot/Trunk Lamps | <ul style="list-style-type: none"> Luggage compartment lamp control circuit - open circuit | Refer to the electrical circuit diagrams and check luggage compartment lamp control circuit for open circuit |
| B111E-15 | Boot/Trunk Lamps - circuit short to battery or open | <ul style="list-style-type: none"> Luggage compartment lamp inoperative Luggage compartment lamp control circuit - short circuit to power, open circuit, high resistance | <ul style="list-style-type: none"> Refer to the electrical circuit diagrams and check luggage compartment lamp control circuit for short circuit to power, open circuit, high resistance. Repair wiring harness as required. Clear DTC and retest |
| B112312 | Restraints Ignition Relay | <ul style="list-style-type: none"> High Side output not driven - diagnosis feedback indicates output is short to power | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check restraints ignition relay output for short to power |
| B112314 | Restraints Ignition Relay | <ul style="list-style-type: none"> High Side output not driven - diagnosis feedback indicates output is short to ground, open circuit | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check restraints ignition relay output for short to ground, open circuit |
| B112393 | Restraints Ignition Relay | <ul style="list-style-type: none"> High Side output not driven - diagnosis feedback indicates output is at open load or short to power | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check restraints ignition relay output for open load or short to power |
| B112411 | Lamp Fade Control | <ul style="list-style-type: none"> Interior lamp fade control circuit - short to ground | Refer to the electrical circuit diagrams and check interior lamp fade control circuit for short to ground |
| B112412 | Lamp Fade Control | <ul style="list-style-type: none"> Interior lamp fade control circuit - short to power | Refer to the electrical circuit diagrams and check interior lamp fade control circuit for short to power |
| B113C12 | Hazard Switch Illumination | <ul style="list-style-type: none"> Hazard switch illumination control circuit - short to power | Refer to the electrical circuit diagrams and check hazard switch illumination control circuit for short to power |
| B113C14 | Hazard Switch Illumination | <ul style="list-style-type: none"> Hazard switch illumination control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check hazard switch illumination control circuit for short to ground, open circuit |
| B113E12 | External Boot/Trunk Release Switch | <ul style="list-style-type: none"> External luggage compartment lid release switch digital input circuit - short to power | Refer to the electrical circuit diagrams and check external luggage compartment lid release switch digital input circuit for short to power |
| B113E23 | External Boot/Trunk Release Switch | <ul style="list-style-type: none"> External luggage compartment lid release switch digital input circuit - signal stuck low | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check external luggage compartment lid release switch digital input circuit for short to ground |
| B11D949 | Vehicle Battery | <ul style="list-style-type: none"> Vehicle battery damaged/worn out | Check battery is in fully charged and serviceable condition using the Midtronics battery tester and the battery care manual |
| B11DB49 | Battery Monitoring Module | <ul style="list-style-type: none"> Internal electronic failure | Suspect the battery monitoring module. Check and install a new module as required, refer to the new module/component installation note at the top of the DTC Index |
| B11DB87 | Battery Monitoring Module | <ul style="list-style-type: none"> Battery monitoring module connector dis-connected/poor connection Battery monitoring module to RJB LIN circuit - open circuit | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. If additional DTCs B108783, B108786, B108787 are logged, suspect the RJB. Check and install a new RJB as required, refer to the new module/component installation note at the top of the DTC Index. If additional DTCs B108783, B108786, B108787 are NOT logged, check for good/clean contact at battery monitoring module |

| DTC | Description | Possible Causes | Action |
|------------|---|---|--|
| | | <ul style="list-style-type: none"> Battery monitoring module to battery positive monitor circuit - open circuit Battery monitoring module/RJB failure | connector, refer to electrical circuit diagrams and check battery monitoring module to RJB LIN circuit and battery monitoring module to battery positive monitor circuit for open circuit. Clear DTC and repeat automated diagnostic procedure using manufacturer approved diagnostic system. If DTC remains suspect the battery monitoring module, check and install a new battery monitoring module as required, refer to the new module/component installation note at the top of the DTC Index |
| B123A11 | Left Front Turn Indicator | <ul style="list-style-type: none"> Left front turn signal lamp control circuit - short to ground | Refer to the electrical circuit diagrams and check left front turn signal lamp control circuit for short to ground |
| B123A12 | Left Front Turn Indicator | <ul style="list-style-type: none"> Left front turn signal lamp control circuit - short to power | Refer to the electrical circuit diagrams and check left front turn signal lamp control circuit for short to power |
| B123A13 | Left Front Turn Indicator | <ul style="list-style-type: none"> Left front turn signal lamp control circuit - open circuit | Refer to the electrical circuit diagrams and check left front turn signal lamp control circuit for open circuit |
| B123A-15 | Left Front Turn Indicator - circuit short to battery or open | <ul style="list-style-type: none"> Left front turn signal lamp control circuit - short circuit to power, open circuit, high resistance | <ul style="list-style-type: none"> Refer to electrical circuit diagrams and check left front turn signal lamp control circuit for short circuit to power, open circuit, high resistance. Repair wiring harness as required. Clear DTC and retest |
| B123B11 | Right Front Turn Indicator | <ul style="list-style-type: none"> Right front turn signal lamp control circuit - short to ground | Refer to the electrical circuit diagrams and check right front turn signal lamp control circuit for short to ground |
| B123B12 | Right Front Turn Indicator | <ul style="list-style-type: none"> Right front turn signal lamp control circuit - short to power | Refer to the electrical circuit diagrams and check right front turn signal lamp control circuit for short to power |
| B123B13 | Right Front Turn Indicator | <ul style="list-style-type: none"> Right front turn signal lamp control circuit - open circuit | Refer to the electrical circuit diagrams and check right front turn signal lamp control circuit for open circuit |
| B123B-15 | Right Front Turn Indicator - circuit short to battery or open | <ul style="list-style-type: none"> Right front turn signal lamp control circuit - short circuit to power, open circuit, high resistance | <ul style="list-style-type: none"> Refer to electrical circuit diagrams and check right front turn signal lamp control circuit for short circuit to power, open circuit, high resistance. Repair wiring harness as required. Clear DTC and retest |
| B124711 | Left Rear Turn Indicator | <ul style="list-style-type: none"> Left rear turn signal lamp control circuit - short to ground | Refer to the electrical circuit diagrams and check left rear turn signal lamp control circuit for short to ground |
| B124712 | Left Rear Turn Indicator | <ul style="list-style-type: none"> Left rear turn signal lamp control circuit - short to power | Refer to the electrical circuit diagrams and check left rear turn signal lamp control circuit for short to power |
| B124713 | Left Rear Turn Indicator | <ul style="list-style-type: none"> Left rear turn signal lamp control circuit - short to power, open circuit | Refer to the electrical circuit diagrams and check left rear turn signal lamp control circuit for open circuit |
| B1247-15 | Left Rear Turn Indicator - circuit short to battery or open | <ul style="list-style-type: none"> Left rear turn signal lamp control circuit - short circuit to power, open circuit, high resistance | <ul style="list-style-type: none"> Refer to electrical circuit diagrams and check left rear turn signal lamp control circuit for short circuit to power, open circuit, high resistance. Repair wiring harness as required. Clear DTC and retest |
| B124811 | Right Rear Turn Indicator | <ul style="list-style-type: none"> Right rear turn signal lamp control circuit - short to ground | Refer to the electrical circuit diagrams and check right rear turn signal lamp control circuit for short to ground |

| DTC | Description | Possible Causes | Action |
|------------|--|---|---|
| B124812 | Right Rear Turn Indicator | <ul style="list-style-type: none"> Right rear turn signal lamp control circuit - short to power | Refer to the electrical circuit diagrams and check right rear turn signal lamp control circuit for short to power |
| B124813 | Right Rear Turn Indicator | <ul style="list-style-type: none"> Right rear turn signal lamp control circuit - open circuit | Refer to the electrical circuit diagrams and check right rear turn signal lamp control circuit for open circuit |
| B1248-15 | Right Rear Turn Indicator - circuit short to battery or open | <ul style="list-style-type: none"> Right rear turn signal lamp control circuit - short circuit to power, open circuit, high resistance | <ul style="list-style-type: none"> Refer to electrical circuit diagrams and check right rear turn signal lamp control circuit for short circuit to power, open circuit, high resistance. Repair wiring harness as required. Clear DTC and retest |
| B126113 | Fuel Flap/Door Release Switch | <ul style="list-style-type: none"> Fuel filler flap digital input signal circuit - open circuit | Refer to the electrical circuit diagrams and check fuel filler flap digital input signal circuit for open circuit |
| B1A7911 | Rear Fog Lamp | <ul style="list-style-type: none"> Rear fog lamp control circuit - short to ground | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check rear fog lamp control circuit for short to ground |
| B1A7912 | Rear Fog Lamp | <ul style="list-style-type: none"> Rear fog lamp control circuit - short to power | Refer to the electrical circuit diagrams and check rear fog lamp control circuit for short to power |
| B1A7913 | Rear Fog Lamp | <ul style="list-style-type: none"> Rear fog lamp control circuit - open circuit | Refer to the electrical circuit diagrams and check rear fog lamp control circuit for open circuit |
| B1C5512 | Horn Relay | <ul style="list-style-type: none"> Horn control circuit - short to power | Refer to the electrical circuit diagrams and check horn control circuit for short to power |
| B1C5514 | Horn Relay | <ul style="list-style-type: none"> Horn control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check horn control circuit for short to ground, open circuit |
| B1C8312 | Rear Defog Relay | <ul style="list-style-type: none"> High Side output not driven - diagnosis feedback indicates output is short to power | Refer to the electrical circuit diagrams and check heated rear window power supply circuit for short to power |
| B1C8314 | Rear Defog Relay | <ul style="list-style-type: none"> High Side output not driven - diagnosis feedback indicates output is short to ground, open circuit | Refer to the electrical circuit diagrams and check heated rear window power supply circuit for short to ground, open circuit |
| B1C8393 | Rear Defog Relay | <ul style="list-style-type: none"> High Side output not driven - diagnosis feedback indicates output is at open load or short to power | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check heated rear window power supply circuit for open load and short to power |
| B1C9112 | Fuel Flap/Door Lock Relay Coil Circuit | <ul style="list-style-type: none"> Fuel filler flap locking motor control circuit - short to power | Refer to the electrical circuit diagrams and check fuel filler flap locking motor control circuit for short to power |
| B1C9114 | Fuel Flap/Door Lock Relay Coil Circuit | <ul style="list-style-type: none"> Fuel filler flap locking motor control circuit - short to ground, open circuit | Refer to the electrical circuit diagrams and check fuel filler flap locking motor control circuit for short to ground, open circuit |
| B1D3512 | Hazard Switch | <ul style="list-style-type: none"> Hazard warning lamp switch digital input circuit - short to power | Refer to the electrical circuit diagrams and check hazard warning lamp switch digital input circuit for short to power |

| DTC | Description | Possible Causes | Action |
|------------|---|---|---|
| B1D3523 | Hazard Switch | <ul style="list-style-type: none"> Hazard warning lamp switch digital input circuit - signal stuck low | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system. Refer to the electrical circuit diagrams and check hazard warning lamp switch digital input circuit for short to ground |
| U001988 | Low Speed CAN Communication Bus | <ul style="list-style-type: none"> Bus off | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system |
| U014000 | Lost Communication With Body Control Module | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system |
| U015500 | Lost Communication With Instrument Panel Cluster (IPC) Control Module | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system |
| U015900 | Lost Communication With Parking Assist Control Module "A" | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system |
| U016400 | Lost Communication With HVAC Control Module | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system |
| U021400 | Lost Communication With Remote Function Actuation | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system |
| U030046 | Internal Control Module Software Incompatibility | <ul style="list-style-type: none"> Calibration/parameter memory failure | Suspect the RJB. Check and install a new RJB as required, refer to the new module/component installation note at the top of the DTC Index |
| U100000 | Solid State Driver Protection Active -Driver Disabled | <ul style="list-style-type: none"> No sub type information | Carry out any pinpoint test associated with this DTC using the manufacturer approved diagnostic system |
| U1A1449 | CAN Initialisation Failure | <ul style="list-style-type: none"> Internal electronic failure | Suspect the RJB. Check and install a new RJB as required, refer to the new module/component installation note at the top of the DTC Index |
| U300049 | Control Module | <ul style="list-style-type: none"> Internal electronic failure | Suspect the RJB. Check and install a new RJB as required, refer to the new module/component installation note at the top of the DTC Index |
| U300055 | Control Module | <ul style="list-style-type: none"> Not configured | Re-configure the RJB using the manufacturer approved diagnostic system |

Module Communications Network - Auxiliary Junction Box (AJB)

Removal and Installation


Removal



NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Battery Disconnect and Connect](#) (414-01 Battery, Mounting and Cables, General Procedures).
2. Refer to: [Loadspace Trim Panel RH](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

3.



Installation

1. To install, reverse the removal procedure.
2. If a new component has been installed, configure using Jaguar approved diagnostic equipment.

Module Communications Network - Central Junction Box (CJB)

Removal and Installation

Removal




NOTE: Removal steps in this procedure may contain installation details.

All vehicles

1. Refer to: [Battery Disconnect and Connect](#) (414-01 Battery, Mounting and Cables, General Procedures).
2. Refer to: [Cowl Side Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).


Left-hand drive vehicles

3.




All vehicles

4.



5.



Installation

1. To install, reverse the removal procedure.
2. Configure the CJB using the diagnostic tool.

Wiring Harnesses - Wiring Harness

Description and Operation

Introduction



CAUTION: Do **not** use any other heat shrink sleeve other than the approved glue lined heat shrink sleeve mentioned in the repair procedure.

The purpose of this document is to promote quick and efficient minor repair to harness connectors or cables using approved methods. Repairs may only be made to cables and connectors which have been mechanically, **not electrically** damaged. It also applies where the whole extent of the damage can be clearly identified and rectified.

Care and neatness are essential requirements in making a perfect repair.

Caution:

This harness repair guide, does not approve repairs to any of the following circuits:

1. Any media orientated system transport network harnesses.
2. Supplement restraint system (SRS) firing circuits (Air bags).
3. Link lead assemblies, which are unique to safety critical circuits such as anti-lock brake system (ABS) and thermocouple circuits. An example of this is the ABS wheel speed sensors with moulded connectors.
4. 4. Screened cables, leads and wiring harness(s).

If any harness(s) with defective electrical connector terminals or wires from the above circuits are a concern, new components must be installed.

Repair Components



CAUTION: Where the repair procedure indicates that a glue lined heat shrink sleeve should be applied, apply sufficient heat to the glue lined heat shrink to melt the glue in order to provide a water tight seal. Do **not** over heat the glue lined heat shrink sleeve so that the wiring harness insulation becomes damaged.

The wiring harness repair components comprises:

- Pre-terminated wiring harness(s) of different sizes and types
- Three sizes of butt splice connectors
- A selection of colored cable identification sleeves
- Two sizes of glue lined heat shrink sleeves

A suitable heat source, for shrinking heat shrink sleeves will be required.

The pre-insulated diamond grip range of electrical connector terminals and in-line, butt splice connectors are the **only** acceptable product for the repairs of wiring harnesses. The butt connectors not only grip the wire but also the insulation, making a very secure joint.


If an electrical connector terminal is not available approval for the repair is **NOT** given and in these circumstances a new wiring harness must be installed.

Pre-Terminated Wiring Harness(s) and Butt Splice Connectors

The pre-terminated wiring harness(s) are supplied with the insulation in one of three colors, red, blue or yellow. The colors do not apply to any particular circuit but to the harness wire size. See the Relationship Table in the Repair Method section.

Butt splice connectors are also supplied with red, blue or yellow coverings, which must be matched to the pre-terminated wiring harness insulation color.

Pre-Terminated Wiring Harness(s)



E130741

The illustration shows:

- The pre-terminated wiring harness(s) which are available via Jaguar/Land Rover authorised parts.
- The part number of the pre-terminated wiring harness
- The letter showing the extractor tip which must be used to remove this type of electrical connector terminal
- Those electrical connector terminals which are gold

Some of the pre-terminated wiring harness(s) have seals installed to the insulation for sealed connector applications. It is

essential for prevention of moisture ingress that a sealed pre-terminated wiring harness must be used where a sealed terminal was removed.



CAUTION: Where the repair procedure indicates that a glue lined heat shrink sleeve should be applied, apply sufficient heat to the glue lined heat shrink to melt the glue in order to provide a water tight seal. Do **not** over heat the glue lined heat shrink sleeve so that the wiring harness insulation becomes damaged.

Two sizes of heat shrink sleeving are available. Each heat shrink sleeve contains a sealant glue. These must be used when connecting wiring harness(s) or electrical connector terminal(s) at all times. The smaller diameter heat shrink sleeve is to be used with the red and blue butt splice connectors and the larger diameter sleeve with the yellow butt splice connectors.

For ease and speed, some of the pre-terminated wiring harness(s) may already have the insulation partly stripped at the splice end. If the repair requires insulation to be stripped from the cable, refer to the Relationship Table for the correct length of insulation to be stripped.

The Pre-Terminated Wiring Harness(s) illustration shows the electrical connector terminal type, the part number of the pre-terminated wiring harness and the letter of the extractor tip which must be used to extract the electrical connector terminal from the connector housing. Additionally, those electrical connector terminal(s) which are gold are identified, all others are therefore, tinned and not gold.

Wiring Harness Cable Identification Sleeves

A selection of colored sleeves are available for maintaining the wiring harness cable identification on the pre-terminated wiring harness. Place the correct colored sleeve(s) over the pre-terminated wiring harness insulation as near to the electrical connector as possible with the main wiring harness cable color nearest to the electrical connector.

For example, if the original wiring harness cable color is pink with a black trace put the pink wiring harness cable identification sleeve on the pre-terminated wiring harness first followed by a black sleeve, and slide both along the wiring harness cable to the electrical connector terminal.

List of Parts

| Description | Part Number | Quantity |
|---|------------------------------|-------------|
| Pre-Terminated Wiring Harness(s) | 418-066 to 418-103 inclusive | 10 each |
| Glue Lined Heat Shrink Pack – small diameter | 418-104 | 25 per pack |
| Glue Lined Heat Shrink Pack – larger diameter | 418-105 | 10 per pack |
| Case Assembly Comprising – carry case, lid, inner lid, base, insert, trays foam spacers | 418-106 | 1 |
| Butt Splice Connector – Red | 418-107 | 50 per pack |
| Butt Splice Connector – Blue | 418-108 | 50 per pack |
| Butt Splice Connector – Yellow | 418-109 | 20 per pack |
| Sleeve Identification Pack – for Red insulation | 418-112 | 500 |
| Sleeve Identification Pack – for Blue insulation | 418-113 | 500 |
| Sleeve Identification Pack – for Yellow insulation | 418-114 | 500 |

Harness repair components can be ordered from Jaguar/Land Rover authorised parts.

Repair Tools



The wiring harness repair tools comprises:

- Crimping pliers
- A wire cutter and insulation stripper
- An electrical connector terminal extraction handle and tips

Extraction Handle and Tips

The extraction handle, in conjunction with the correct tip, is used to remove a terminal from an electrical connector. Each tip is marked with an identification letter, A to K inclusive. Each tip has been specially designed to extract a particular type of electrical connector terminal. The use of any other tool is **not** recommended and is liable to cause damage to the electrical connector. The tip is fastened to the handle by a screw which holds the tip firmly yet allows it to be easily replaced.

Extraction Handle and Tips




E130742

Insulation Stripper

The moving jaw has an adjuster wheel which has a series of holes in it. Turning the wheel and placing the cable in the matching size hole will automatically adjust the jaw to the correct pressure. Note that some wiring harness(s) may have a harder insulation and slight adjustment of the wheel may be needed to make a clean strip but exercise care not to damage the wire.

Insulation Stripper




E130743

By pressing the outer edges of the wiring harness cable length stop together the adjuster can be slid up or down the jaw. This decreases or increases the length by which the wiring harness cable insulation will be stripped from the pre-terminated wiring harness or wiring harness wire. The adjuster has a position indicator to align with a graduated scale and this sets the correct length in millimetres, of insulation to be stripped. The amount of insulation to be stripped is shown in the Relationship Table.

The illustration shows the insulation stripper tool and a wiring harness correctly gripped in the jaws. A wire cutter is provided on the outer side of the fixed jaw.


Cable Correctly Gripped in Stripper Blades



E130744

Crimping Pliers

Crimping Pliers



E130745

The crimping pliers have a moving jaw and a stationary jaw, with three different sized crimping enclosures. Each of the enclosures is identified by a red, blue or yellow coloured dot which corresponds to the three colours of the pre-terminated wiring harness(s) and butt splice connector colors.

| Description | Part Number | Quantity |
|---|-------------|----------|
| Extraction Tool Handle | 418-110 | 1 |
| Extraction Tip Pack consists of 2 spare screws plus | 418-S111 | 1 |
| Tip A | 418-118 | 1 |
| Tip B | 418-119 | 1 |
| Tip C | 418-120 | 1 |
| Tip D | 418-121 | 1 |
| Tip E | 418-122 | 1 |
| Tip F | 418-123 | 1 |
| Tip G | 418-124 | 1 |
| Tip H | 418-125 | 1 |
| Tip I | 418-126 | 1 |
| Tip J | 418-127 | 1 |
| Tip K | 418-128 | 1 |
| Crimping Pliers | YRW500010 | 1 |
| Wire Stripping Tool | 418-117 | 1 |
| | | |
| | | |

Harness repair tools can be ordered from:

Bosch Automotive Service Solutions

Ironstone Way

Brixworth Industrial Estate

Brixworth

Northants

NN6 9UD

United Kingdom

Telephone: +44 (0) 1327 303400

Fax: +44 (0) 1327 303499

Email: css.uk@bosch-automotive.com

Repair Methods



CAUTION: Several different types and sizes of terminal may be found in a single electrical connector housing.

It is necessary to identify:

- The conductor (wire) size of the affected wiring harness
- The electrical connector range from which the damaged wiring harness is to be removed
- The terminal type

Use of the approved diagnostic tool will greatly assist in the quick identification of electrical connectors and faulty pin terminal(s).

Reference can also be made to the vehicle Electrical Guides, held by Dealers, to identify wiring harness(s) and electrical connector(s).

By using the Relationship Table, the wiring harness conductor (wire) size can be related to a suitable pre-terminated wiring harness by the color of the insulation. Also, the correct length of insulation to be stripped from the wiring harness lead is identified.

Relationship Table

| CABLE RANGE | SPLICE | STRIP LENGTH |
|--|--------|-----------------|
| 0.35 mm ² to 1.50 mm ² | RED | 6.00 to 7.00 mm |
| 1.00 mm ² to 2.50 mm ² | BLUE | 6.00 to 7.00 mm |
| 4.00 mm ² to 6.00 mm ² | YELLOW | 9.00 to 9.50 mm |

Electrical Connector Terminal Extraction


It must be noted that some electrical connector(s) have anti-backout devices which prevent the terminals from being removed from the electrical connector. Some examples of these are shown in following illustrations. The anti-backout device must be released before attempting to remove the terminal from the electrical connector. Some anti-backout devices require a special tip to release the device. Most can be released by carefully using a suitable small screwdriver.


Various types of electrical connector have seals installed internally or externally to prevent moisture ingress. These normally do not have to be removed but make sure that they are installed when the electrical connectors are connected.

The illustrations show examples of each tip used on different types of electrical connector(s). There are a large number of different types of electrical connector used on vehicles therefore only one example using each tip is shown. Technicians experience and judgement will dictate which type of tip should be used for those electrical connector(s) which are not shown. Care should be exercised to avoid further damage when removing the terminals from the electrical connector.




NOTE: Examples of the extraction tips and anti-backout tips.








E130747




131748



131749





E




'131750

E





EIJ07SI



I





E130752



131753



131754



131755



NOTE: The chart shows the electrical connector types, terminal pins/sockets, extractor tip and anti-backout tip.

| Electrical connector terminal type | Pin or socket | Extractor tip | Anti-backout tip |
|------------------------------------|---------------|---------------|------------------|
| Multilock 040 series | D | A | |
| Multilock 040 series | B | A | |
| Multilock 070 series | B | B | |
| Multilock 040 series | D | B | |
| Econoseal III 070 series | D | B | |
| Econoseal III 070 series | B | B | |
| Econoseal III 070 series | B | B | |
| Econoseal III J2 | D | B | |
| Econoseal III 250 series | B | F | |
| Econoseal III 250 series | D | B | |
| Econoseal III 250 series | B | F | |
| Econoseal III 250 series | D | B | |
| Micro-timer II 1.5mm | D | C | |
| Micro-timer II 1.5mm | B | C | |
| Std power timer 4.8 flat | D | G | |
| Std power timer 5.8 flat | B | D | |
| Std power timer 5.8 flat | B | D | |
| Std power timer 2.8 flat | D | D | |
| Std power timer 4.8 flat | D | G | |
| Std power timer 5.8 flat | B | D | |
| Ford 2.8 flat | D | E | H |
| Multilock 070 series | D | B | |
| Multilock 070 series | B | B | |
| Junior power timer 2.8 flat | D | D | |
| Sumitomo TS90 connector | B | B | H |
| Modu IV gold plated | D | B | |
| Multilock 040 series gold plated | D | A | |
| Micro qualock | D | I | |
| EECV | D | B | |
| EECV | D | B | |
| Kostal dia 1.50 series | D | J | |
| AMP 6.3 flat | D | B | |
| Junior power timer 2.8 flat | D | D | |
| 2.8 series | D | B | I |
| Sumitomo TS90 connector | D | B | H |
| Ducon 0.60 gold plated | D | K | |
| AMP 6.3 flat | D | D | |
| Econoseal III 250 series | B | F | |

Repair Procedure

CAUTIONS:




Do not use crimping pliers, insulation strippers, butt splice connectors, heat shrink sleeves or pre-terminated wiring harness(s) that are not supplied with by authorised Jaguar/Land Rover parts. Each part has been designed to be used only with the other parts available from Jaguar/Land Rover parts.



Where the repair procedure indicates that a glue lined heat shrink sleeve should be applied, apply sufficient heat to the glue lined heat shrink to melt the glue in order to provide a water tight seal. Do **not** over heat the glue lined heat shrink sleeve so that the wiring harness insulation becomes damaged.

It is not correct to make more than five repair joints on the wiring harness to any electrical connector and if more damage is found at the same electrical connector then a new wiring harness must be installed.

1. Remove the faulty terminal from the electrical connector using the extractor tool and correct tip. Make sure that any anti-backout device is released before trying to remove the terminal.
2.  CAUTION: A number of electrical connector terminals are gold plated or gold flashed. When defective, they must be installed with a gold pre-terminated wiring harness(s). It is not always easy to identify the female as gold but the male pins are visually easier, therefore always check both male and female terminals to identify those which are gold. Under no circumstances are gold and tin terminals to be mixed as this will lead to early failure of the electrical contact.



NOTE: Never use a harness lead with a smaller diameter than the original harness lead.

Select the correct size and type of pre-terminated wiring harness and butt splice connector.

3. Using the wire cutter on the stripping tool, cut the pre-terminated wiring harness and the harness cable to the required

length.

4.  NOTE: See illustration: **Stripping Insulation**


From the Relationship Table, find the correct length of insulation to be stripped from the pre-terminated wiring harness and set the adjustable cable length stop to the correct length. Place the pre-terminated wiring harness in the wire stripper and remove the insulation.

5. Put the cable identification sleeve(s) on to the wiring harness with the main cable colour nearest to the terminal.
6. During this next step do not over tighten. Place the selected butt splice connector in the crimping tool, matching the aperture and the butt connector colours. Make sure that the window indentation in the butt connector is resting over the guide bar on the lower jaw. Partially close the grip until the butt connector is securely held in the aperture. This will give support to the butt connector while the pre-terminated wiring harness is inserted into it.

7.  NOTE: See illustration: **Splice Correctly Located**

Insert the pre-terminated wiring harness into the butt connector and make sure that the wire is against the wire stop. Close the grip firmly, crimping the lead to the butt connector. When the handles have been completely closed the butt connector will be freed from the tool as the handles are released. If the handles have not been completely closed then the jaws will hold the butt connector and it cannot be removed from the tool until the crimp is fully made by closing the handles completely.

8. Make sure that the harness cable has been squarely cut and the correct length of insulation removed. If more than one splice is needed the butt connectors must not be crimped to the wiring harness at the same distance from the connector. The splices must be staggered to prevent a bulk of splices in the same area of the wiring harness.
9. It is preferable to cover the butt splice joint with heat shrink sleeve. This is desirable not essential, except where the electrical connector is a sealed electrical connector. Use the smaller diameter sleeve for red and blue pre-terminated wiring harness(s) and the large diameter sleeve for the yellow pre-terminated wiring harness(s). It is advisable to place the heat shrink over the completed joint but in some instances the sleeve will not pass over the terminal. Check, and if required, place the correct size sleeve onto the harness cable or pre-terminated wiring harness before crimping the butt splice to the wiring harness.
10. Place the harness cable into the butt splice with the splice window over the guide bar. Make sure that the cable harness wire is against the stop in the butt splice, crimp the butt splice connector to the wiring harness.
11. Gently pull the harness cables each side of the butt splice to make sure that a secure joint has been made.

12.  WARNING: Do not use a naked flame in areas where fuel or oil have been spilt. Clean the area of residual oil and fuel and wait until the fuel spill has fully evaporated.

CAUTIONS:



When using a heat source make sure that it is localised and causes no damage to surrounding materials.




Where the repair procedure indicates that a glue lined heat shrink sleeve should be applied, apply sufficient heat to the glue lined heat shrink to melt the glue in order to provide a water tight seal. Do **not** over heat the glue lined heat shrink sleeve so that the wiring harness insulation becomes damaged.

Using a suitable heat source, shrink the sleeve over the butt splice.


13. If further pre-terminated wiring harness(s) are to be installed to the same electrical connector, make sure that the lead is cut at a different length to the previous joint. This makes sure that the splices will, where possible, be staggered on the wiring harness and prevent a bulk of splices in one area.
14. When all of the splices have been made, fit the terminal(s) to the electrical connector, taking care that the terminals are correctly orientated.
15. Install the wiring harness cover and secure with adhesive electrical tape. Do not cover the wiring harness right to the electrical connector as the terminals must have a little movement and not be firmly bound to the electrical connector or wiring harness. Make sure that the cable identification sleeve(s) are showing at the wiring harness electrical connector.

Stripping Insulation



E130756

Splice Correctly Located



E130757

Wiring Harnesses - Wiring Harness Repair

General Procedures

1. For additional information, refer to: [Wiring Harness](#) (418-02 Wiring Harnesses, Description and Operation).

Wiring Harnesses - Luggage Compartment Lid Wiring Harness


Removal and Installation

Removal

1. Remove the luggage compartment lid trim panel.


Refer to: [Luggage Compartment Lid Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

- 2.



E93085

- 3.



E93086

Installation

1. To install, reverse the removal procedure.