



# DTC Summaries

## Electromechanical Airbag SRS: XK8 1997 ON

---

DTCs are stored in the diagnostic module nonvolatile memory and can be accessed only through the DLC (diagnostic link connector) using PDU.

**⚠ CAUTION:** Measuring the resistance of airbag circuits may cause airbag deployment. Refer to the service literature for safe testing procedures. Observe all safety precautions when diagnosing or repairing airbag SRS systems.

| DTC   | FAULT DESCRIPTION   | MONITORING CONDITIONS                        | MIL ACTIVATED | POSSIBLE CAUSES   |
|-------|---|--|---------------|---|
| B1342 | Internal diagnostic module fault  | Switch ignition ON for more than 10 seconds  | YES           | Diagnostic module failure   |
| B1867 | B+ voltage supply low (< 5 V)<br>(Repair causes of any other logged DTCs before repairing B1867)  | Switch ignition ON for more than 10 seconds  | YES           | B+ voltage to diagnostic module circuit: open circuit, high resistance or short circuit to ground   |
| B1869 | Diagnostic module "beeps" 5 times every 30 minutes<br>(Repair causes of any other logged DTCs before repairing B1869)   | Switch ignition ON                           | —             | AIRBAG SRS MIL failure plus additional airbag SRS system faults: Refer to "No AIRBAG SRS MIL" near the end of this summary  |
| B1913 | Airbag circuit short circuit<br>(DTC 1913 will cause airbag SRS system 10 A battery fuse to open circuit, flagging DTC B1867. Repair cause of DTC B1913 first.)                   | Switch ignition ON for more than 3 minutes.  | YES           | Passenger or driver airbag to diagnostic module: short circuit to ground<br>Passenger or driver airbag: internal short circuit to ground<br>Driver airbag cassette: short circuit to ground<br>Diagnostic module to impact sensor voltage supply circuit: high resistance or short circuit to ground<br>Impact sensor to airbag circuits: short circuit to ground<br>Impact sensor to ground: high resistance |
| B1914 | Impact sensor circuit short circuit to ground<br>(DTC B1914 will cause airbag SRS system 10 A battery fuse to open circuit, flagging DTC B1867. Repair cause of DTC B1914 first.) | Switch ignition ON for more than 3 minutes.  | YES           | Diagnostic module to impact sensor voltage supply circuit: open circuit, high resistance or short circuit to ground<br>Impact sensor failure  |
| B1921 | Diagnostic module poor ground (> 3.0 Ω)   | Switch ignition ON for more than 10 seconds. | YES           | Diagnostic module to vehicle ground: high resistance<br>Diagnostic module failure   |
| B1922 | Safing sensor voltage high (> 5 V)  | Switch ignition ON for more than 10 seconds. | YES           | Charging system voltage above 17 V<br>Diagnostic module to airbag harness: short circuit to B+ voltage<br>Cable reel cassette: short circuit to B+ voltage<br>Diagnostic module failure   |
| B1923 | Diagnostic module fault (memory clear circuit)  | Switch ignition ON for 30 seconds            | YES           | Diagnostic module failure   |

| DTC   | FAULT DESCRIPTION   | MONITORING CONDITIONS                        | MIL ACTIVATED | POSSIBLE CAUSES   |
|-------|---|--|---------------|---|
| B1924 | Diagnostic module "fuse blow" circuit fault                       | Switch ignition ON for more than 3 minutes.  | YES           | Diagnostic module B+ voltage supply circuit:<br>open circuit or high resistance<br>Diagnostic module to impact sensor circuits:<br>open circuit or high resistance<br>Impact sensor ground circuit: high resistance<br>Impact sensor failure<br>Diagnostic module failure |
| B1932 | Driver airbag circuit high resistance<br>(above 3.5 $\Omega$ )    | Switch ignition ON for more than 30 seconds. | YES           | Diagnostic module to driver side cable reel cassette<br>harness: open circuit or high resistance<br>Cable reel cassette: open circuit or high resistance<br>Driver side airbag: open circuit or high resistance<br>Diagnostic module failure                              |
| B1933 | Passenger airbag circuit high resistance<br>(above 2.5 $\Omega$ ) | Switch ignition ON for more than 30 seconds  | YES           | Diagnostic module to passenger side airbag harness:<br>open circuit or high resistance<br>Passenger side airbag: open circuit or high resistance<br>Diagnostic module failure   |
| B1934 | Driver airbag circuit low resistance<br>(below 1 $\Omega$ )       | Switch ignition ON for more than 30 seconds. | YES           | Diagnostic module to driver side cable reel cassette<br>harness: short circuit<br>Driver side cable reel cassette: short circuit<br>Driver side airbag: short circuit<br>Diagnostic module failure  |
| B1935 | Passenger airbag circuit low resistance<br>(below 0.7 $\Omega$ )  | Switch ignition ON for more than 30 seconds. | YES           | Diagnostic module to passenger side airbag harness:<br>short circuit<br>Passenger side airbag: short circuit<br>Diagnostic module failure   |
| B1941 | Right side impact sensor supply circuit<br>high resistance        | Switch ignition ON for more than 30 seconds. | YES           | Diagnostic module to impact sensor harness circuits:<br>open circuit, high resistance or short circuit<br>to B+ voltage<br>Impact sensor failure<br>Diagnostic module failure   |

| DTC    | FAULT DESCRIPTION   | MONITORING CONDITIONS                        | MIL ACTIVATED       | POSSIBLE CAUSES  |
|--------|---|--|---------------------|--|
| B1942  | Left side impact sensor supply circuit high resistance                          | Switch ignition ON for more than 30 seconds. | YES                 | Diagnostic module to impact sensor harness circuits: open circuit, high resistance or short circuit to B+ voltage<br>Left impact sensor failure<br>Diagnostic module failure   |
| B1944  | Right impact sensor poor ground   | Switch ignition ON for more than 30 seconds. | YES                 | Sensor to body grounds: loose or corroded<br>Sensor to diagnostic module harness sensor ground circuit: high resistance or open circuit<br>Sensor failure<br>Diagnostic module failure   |
| B1945  | Left impact sensor poor ground  | Switch ignition ON for more than 30 seconds. | YES                 | Sensor to body grounds: loose or corroded<br>Sensor to diagnostic module harness sensor ground circuit: high resistance or open circuit<br>Sensor failure<br>Diagnostic module failure   |
| No DTC | No AIRBAG SRS MIL   | Switch ignition ON.                          | —                   | AIRBAG SRS MIL bulb failure<br>Ignition auxiliary switched circuit to diagnostic module: no voltage or open circuit<br>Instrument pack to diagnostic module AIRBAG SRS MIL circuit: open circuit<br>Diagnostic module failure<br>Instrument pack failure |
| No DTC | AIRBAG SRS MIL stays ON constantly with ignition ON                             | Switch ignition ON for more than 10 seconds. | YES                 | Instrument pack to diagnostic module AIRBAG SRS MIL circuit: open circuit or high resistance<br>Ignition switched voltage to diagnostic module: open circuit, high resistance or short circuit to ground<br>Diagnostic module failure                    |
| No DTC | AIRBAG SRS MIL flashes continuously (DTCs B1941, B1942, B1944 and B1945 logged) | Switch ignition ON for more than 10 seconds. | CONTINUOUS FLASHING | Both impact sensors disconnected<br>Main wiring harness disconnected   |