



Sedan Range

DATE 12/94

18-08

**SERVICE**

**TECHNICAL BULLETIN**

**Security System –  
Erratic Operation or No Start With Transit  
Isolation Relay Fitted**

MODEL 1995 MY  
Sedan Range  
VIN 720001-ON

**ISSUE:**

Erratic operation of the security system or a no start condition on 1995 MY Sedan Range vehicles with the transit isolation relay still fitted to the vehicle.

This condition results from the transit isolation relay disconnecting battery power to the vehicle 30 seconds after the ignition is switched off.

If the vehicle is locked with the key or the security system transmitter within the 30 seconds before battery power is disconnected, the security system arms. The SCM stores this information in non-volatile memory. When the ignition is switched on again, restoring battery power to the vehicle, the security system is still armed.

**NOTE:** The transit isolation relay should remain fitted to the vehicle until 24 hours before delivery to the customer.

**ACTION:**

If the security system operates erratically on Sedan Range vehicles with transit isolation relays fitted or the vehicle will not start, disarm the security system as follows.

1. Switch the ignition ON to energize the transit isolation relay, then switch the ignition OFF.
2. Disarm the security system within 30 seconds by pressing the small button on the security system transmitter.

**NOTE:** The security system must be disarmed before the transit isolation relay disconnects battery power to the vehicle. The transit isolation relay disconnects battery power 30 seconds after the ignition is switched off.